


Location of plug connections



Switches




Fig. 1

- A25/1s1 Soft top compartment cover switch "closed"
- A25/1s2 Soft top compartment cover switch "locked"
- S83/5 Roll-over bar "retracted" switch
- S83/6 Roll-over bar "extended" switch
- S84/1 Left front soft top "locked" switch
- S84/2 Right front soft top "locked" switch
- S84/3 Soft top "open" switch (soft top in compartment)
- S84/4 Soft top "up" switch
- S84/5 Soft top compartment "open" switch
- S84/6 Soft top bow "raised" switch
- S84/7 Soft top bow "lowered" switch
- S84/8 Soft top bow "locked" switch

Switches and control units





Fig. 2

- E30 Roll-over bar indicator lamp
- N52 Soft top control unit
- N53 Roll-over bar control unit (crash actuation)
- S21/7 Rear power window safety switch
- S83 Roll-over bar convenience switch (convenience feature)
- S83/4 Roll-over bar switch
- S84 Soft top actuating switch

Electrical components

Fig. 3

- A7/5 Soft top (roll-over bar) hydraulic unit
- A7/5k1 Relay
- A7/5m1 Motor
- A7/5x Plug connection
- A7/5y1 Main valve
- E15 Dome lamp with shut-off delay and reading lamp
- E15h1 Warning buzzer
- F24 Auxiliary fuse box, soft top/roll-over bar
- F24/1 Auxiliary fuse box, hydraulic unit
- Y55 Right valve block, soft top actuation (4 connections)
- Y55y6 Valve, soft top "open"
- Y55y7 Valve, soft top "closed"
- Y55y8 Valve, soft top bow - raise
- Y55y9 Valve, soft top bow - lower
- Y56 Left valve block, soft top actuation (4 connections)
- Y56y3 Valve, soft top compartment cover lock
- Y56y4 Valve, soft top bow lock
- Y56y5 Valve, soft top compartment cover drive
- Y57 Valve block, roll-over bar
- Y57y10 Valve, rod side
- Y57y11 Valve, piston side



Diagnosis - Troubleshooting chart

Complaint	Possible cause	Remedy/Test step ¹⁾
Indicator lamp in soft top actuating switch (S84) does not burn when ignition is switched on	Control unit (N52)	□23 ⇒ 1.0
	Indicator lamp for soft top actuating switch (S84)	□23 ⇒ 35.0, 36.0
Indicator lamp in soft top actuating switch (S84) burns when soft top is closed (no pulse display) (Gong sounds for approx. 10 s while driving)	Soft top bow "locked" switch (S84/8)	□23 ⇒ 8.0
	Left front soft top "locked" switch (S84/1)	□23 ⇒ 11.0
	Right front soft top "locked" switch (S84/2)	□23 ⇒ 12.0
Indicator lamp in soft top actuating switch (S84) burns with soft top open (no pulse display) (Gong sounds for approx. 10 s while driving)	Soft top compartment cover switch "locked" (A25/1s2)	□23 ⇒ 5.0
	Left front soft top "locked" switch (S84/1)	□23 ⇒ 11.0
	Right front soft top "locked" switch (S84/2)	□23 ⇒ 12.0
Indicator lamp in soft top actuating switch (S84) flashes when pressed	Fault is stored	Display fault code □12/1
Roll-over bar cannot be extended with roll-over bar convenience switch (S83)	Hydraulic unit not running	□23 ⇒ 1.0, 2.0
	Roll-over bar convenience switch (S83)	□23 ⇒ 20.0
	Roll-over bar "extended" switch (S83/6)	□23 ⇒ 16.0
	Valve, extend roll-over bar (Y57y11)	□23 ⇒ 23.0
	System pressure	□33 ⇒ 1.0
	Extend roll-over bar	□33 ⇒ 4.0
Roll-over bar cannot be extended with roll-over bar switch (rear, S83/4)	Roll-over bar switch (rear, S83/4)	□23 ⇒ 20.0
	Power window safety switch (S21/7)	□23 ⇒ 22.0

¹⁾ Observe prerequisites for testing.

Diagnosis - Troubleshooting chart

Complaint	Possible cause	Remedy/Test step ¹⁾
Roll-over bar cannot be extended with soft top actuating switch (S84)	Valve, extend roll-over bar (Y57y11)	□23 ⇒ 23.0
	System pressure	□33 ⇒ 1.0
	Extend roll-over bar	□33 ⇒ 4.0
Roll-over bar cannot be retracted with roll-over bar actuating switch (S83)	Hydraulic unit not running	□23 ⇒ 1.0, 2.0
	Roll-over bar convenience switch (S83)	□23 ⇒ 20.0
	Roll-over bar "retracted" switch (S83/5)	□23 ⇒ 15.0
	Valve, retract roll-over bar (Y57y10)	□23 ⇒ 21.0
	Retract roll-over bar	□33 ⇒ 3.0
Roll-over bar cannot be retracted with roll-over bar switch (rear, S83/4)	Roll-over bar switch (rear, S83/4)	□23 ⇒ 20.0
	Power window safety switch (S21/7)	□23 ⇒ 22.0
Roll-over bar cannot be retracted with soft top actuating switch (S84)	Hydraulic unit not running	□23 ⇒ 1.0, 2.0
	Soft top actuating switch (S84)	□23 ⇒ 18.0
	Roll-over bar "retracted" switch (S83/5)	□23 ⇒ 15.0
	Valve, retract roll-over bar (Y57y10)	□23 ⇒ 21.0
	Retract roll-over bar	□33 ⇒ 3.0
Side windows do not open at start of soft top actuation sequence	Power supply to convenience control unit Convenience control unit (N57)	□23 ⇒ 33.0
Side windows do not close after soft top actuation sequence (catches at front must be locked)	Soft top compartment cover switch "locked" (A25/1s2)	□23 ⇒ 5.0
	Power supply to convenience control unit Convenience control unit (N57)	□23 ⇒ 33.0

¹⁾ Observe prerequisites for testing.

Diagnosis - Troubleshooting chart

Complaint	Possible cause	Remedy/Test step ¹⁾
Heated rear window does not switch off with soft top open	Soft top "up" switch (S84/4)	□23 ⇒ 14.0
	Power supply to combination relay (heated rear window) (N10)	□23 ⇒ 32.0
Soft top cannot be opened or closed while driving (catches at front unlocked). Gong in soft top control unit does not sound.	Speed signal Hall-effect sensor (X53/5)	□23 ⇒ 19.0, 34.0
	Soft top control unit (N52)	
Central closing feature for side windows does not function even after soft top actuating switch (S84) has been actuated twice in direction close	Soft top actuating switch (S84)	□23 ⇒ 18.0
	Power supply to convenience control unit (N57)	□23 ⇒ 33.0

Central opening feature for side windows does not function even after soft top actuating switch (S84) has been actuated twice in direction **open**

Soft top actuating switch (S84)

□23 ⇒ 18.0

Power supply to convenience control unit (N57)
Convenience control unit (N57)

□23 ⇒ 33.0

1) Observe prerequisites for testing.

Diagnosis - Troubleshooting chart

During soft top closing sequence (soft top unlocked at front left and right)

Complaint	Possible cause	Remedy/Test step 1)
Soft top compartment cover lock does not open	Hydraulic unit not running	□23 ⇒ 1.0, 2.0
	Left front soft top "locked" switch (S84/1)	□23 ⇒ 11.0
	Right front soft top "locked" switch (S84/2)	□23 ⇒ 12.0
	Roll-over bar "retracted" switch (S83/5)	□23 ⇒ 15.0
	Soft top actuating switch (S84)	□23 ⇒ 18.0
	Valve, soft top compartment cover lock (Y56y3)	□23 ⇒ 25.0
	Main valve, hydraulic unit (A7/5y1)	□23 ⇒ 24.0
	Roll-over bar (ÜRB) crash-activated trigger unit (N53)	□23 ⇒ 37.0
	System pressure	□33 ⇒ 1.0
	Open soft top compartment cover lock	□33 ⇒ 13.0
Soft top compartment cover does not open, or moves upward too slowly	Valve, soft top compartment cover drive (Y56y5)	□23 ⇒ 27.0
	Raise soft top compartment cover	□33 ⇒ 14.0
Soft top does not come out of soft top compartment or only closes slowly	Soft top compartment "open" switch (S84/5)	□23 ⇒ 7.0
	Valve, soft top closed (Y55y7)	□23 ⇒ 29.0
	Close soft top	□33 ⇒ 15.0
Soft top bow does not move up or moves up too slowly	Soft top "up" switch (S84/4)	□23 ⇒ 14.0
	Valve, soft top bow up (Y55y8)	□23 ⇒ 30.0
	Raise soft top bow	□33 ⇒ 16.0

1) Observe prerequisites for testing.

Diagnosis - Troubleshooting chart

Complaint	Possible cause	Remedy/Test step 1)
Soft top compartment cover does not close or closes too slowly	Soft top bow "raised" switch (S84/6)	□23 ⇒ 10.0
	Valve, soft top bow lock (Y56y4)	□23 ⇒ 26.0
	Valve, soft top compartment cover drive (Y56y5)	□23 ⇒ 27.0
	Lower soft top compartment cover	□33 ⇒ 17.0
Soft top compartment cover lock does not lock	Soft top compartment cover switch "closed" (A25/1s1)	□23 ⇒ 6.0
	Valve, soft top compartment cover lock (Y56y3)	□23 ⇒ 25.0
	Lock soft top compartment cover lock	□33 ⇒ 18.0
Soft top bow does not move down or moves down too slowly	Soft top compartment cover switch "locked" (A25/1s2)	□23 ⇒ 5.0
	Valve, soft top bow closed (Y55y9)	□23 ⇒ 31.0
	Lower soft top bow	□33 ⇒ 19.0
Soft top bow lock does not lock	Soft top bow "lowered" switch (S84/7)	□23 ⇒ 9.0
	Valve, soft top bow lock (Y56y4)	□23 ⇒ 26.0
	Lock soft top bow lock	□33 ⇒ 20.0

1) Observe prerequisites for testing.

Diagnosis - Troubleshooting chart

During soft top opening sequence (soft top unlocked at front left and right)

Complaint	Possible cause	Remedy/Test step 1)
Soft top bow lock does not unlock	Hydraulic unit not running	□23 ⇒ 1.0, 2.0
	Left front soft top "locked" switch (S84/1)	□23 ⇒ 11.0
	Right front soft top "locked" switch (S84/2)	□23 ⇒ 12.0
	Roll-over bar "retracted" switch (S83/5)	□23 ⇒ 15.0
	Soft top actuating switch (S84)	□23 ⇒ 18.0

	Roll-over bar (ÜRB) crash-activated trigger unit (N53)	□23 ⇒ 37.0
	System pressure	□33 ⇒ 1.0
	Open soft top bow lock	□33 ⇒ 5.0
Soft top bow does not move up or moves up too slowly	Soft top bow "locked" switch (S84/8)	□23 ⇒ 8.0
	Valve, soft top bow - raise (Y55y8)	□23 ⇒ 30.0
	Raise soft top bow	□33 ⇒ 6.0
Soft top compartment cover lock does not unlock	Soft top bow "raised" switch (S84/6)	□23 ⇒ 10.0
	Valve, soft top compartment cover lock (Y56y3)	□23 ⇒ 25.0
	Open soft top compartment cover lock	□33 ⇒ 7.0

1) Observe prerequisites for testing.

Diagnosis - Troubleshooting chart

Complaint	Possible cause	Remedy/Test step 1)
Soft top compartment cover does not open or opens too slowly	Valve, soft top compartment cover (Y56y5)	□23 ⇒ 27.0
	Raise soft top compartment cover	□33 ⇒ 8.0
Soft top bow does not go down or goes down too slowly	Soft top compartment "open" switch (S84/5)	□23 ⇒ 7.0
	Valve, soft top bow - lower (Y55y9)	□23 ⇒ 31.0
	Lower soft top bow	□33 ⇒ 9.0
Soft top does not open or opens too slowly	Soft top bow "lowered" switch (S84/7)	□23 ⇒ 9.0
	Valve, soft top open (Y55y6)	□23 ⇒ 28.0
	Open soft top	□33 ⇒ 10.0
Soft top compartment cover does not close or closes too slowly	Soft top "open" switch (S84/3)	□23 ⇒ 13.0
	Valve, soft top bow lock (Y56y4)	□23 ⇒ 26.0
	Valve, soft top compartment cover (Y56y5)	□23 ⇒ 27.0
	Lower soft top compartment cover	□33 ⇒ 11.0
Soft top compartment cover lock does not lock	Soft top compartment cover switch "closed" (A25/1s1)	□23 ⇒ 6.0
	Valve, soft top compartment cover lock (Y56y5)	□23 ⇒ 25.0
	Lock soft top compartment cover lock	□33 ⇒ 12.0

1) Observe prerequisites for testing.

Test program - Electrical system Prerequisites for testing

- Battery voltage 11-14 V (always connect battery charger when working on soft top).
- Roll-over bar switch must not flash (index 19.1).
- Fuses F24, F24/1 and F1/A okay.

See "Electrical circuit diagrams, Designation model 124, volume 4.1" Group 77

Note on testing limit switches

To put control unit in diagnosis mode:

1. Ignition: **OFF**
2. Bridge sockets 1 and 3 on plug connection (X11/12) in passenger footwell (□23, Fig. 1)
3. Ignition: **ON**
4. Remove bridges




The soft top control unit has three different connection possibilities. For this reason subdivision is required in the chapter "Testing":

- Connect socket box according to connection schematic X (□22, Fig. 4): X
- Connect socket box according to connection schematic Y (□22, Fig. 5): Y
- Connect socket box according to connection schematic Z (□22, Fig. 6): Z

Test program - Electrical system Prerequisites for testing

Special tools



Commercially available tools and instruments, MB instruments (see Workshop Equipment Manual)

Designation	e.g. company, order no.
Multimeter	Fluke 23 DB, 83, 88 ITT Metrix MX 47, 50, 51, 52
Battery charger	Bosch, model L 4816, model SL 60100

Test program - Electrical system Prerequisites for testing

- △ Ignition: **OFF**
- Disconnect connector X from control unit
- Connect socket box

Socket box connection schematic with connector X




Fig. 4

- 01 Connector, 12-pin (vehicle cable harness)
- 002 Test cable, 12-pin 129 589 01 63 00
- 003 Multimeter
- 004 Socket box
- N52 Soft top control unit

P77-0006-88


Test program - Electrical system Prerequisites for testing

- △ Ignition: **OFF**
- Disconnect connector Y from control unit
- Connect socket box

Socket box connection schematic with connector Y

Fig. 5

- 01 Connector, 35-pin (vehicle cable harness)
- 002 Test cable, 35-pin 129 589 00 63 00
- 003 Multimeter
- 004 Socket box
- N52 Soft top control unit



Test program - Electrical system


Prerequisites for testing

- ⚠ Ignition: OFF
- Disconnect connector Z from control unit
- Connect socket box

Socket box connection schematic with connector Z

Fig. 6

- 01 Connector, 12-pin (vehicle cable harness)
- 002 Test cable, 12-pin 129 589 01 63 00
- 003 Multimeter
- 004 Socket box
- N52 Soft top control unit



Soft top opening sequence

Limit switches actuated	Soft top			Soft top bow			Soft top compartment cover			Roll-over bar	
	locked	up	open	down	locked	open	closed	locked	open	retracted	extended
	S84/1 S84/2	S84/4	S84/3	S84/7	S84/8	S84/6	A25/1s1	A25/1s2	S84/5	S83/5	S83/6
Socket box, connection schematic Y (□22, fig. 5) Control unit in diagnosis mode □22	Y 5 └┬ 6	Y 7	Y 9	Y 10	Y 11	Y 12	Y 13	Y 14	Y 15	Y 16	Y 17
Soft top unlocked at front, roll-over bar extended	11-14 V	0-1 V	11-14 V	0-1 V	0-1 V	11-14 V	0-1 V	0-1 V	11-14 V	11-14 V	0-1 V
Roll-over bar retracted	11-14 V	0-1 V	11-14 V	0-1 V	0-1 V	11-14 V	0-1 V	0-1 V	11-14 V	0-1 V	11-14 V
Soft top bow unlocked	11-14 V	0-1 V	11-14 V	0-1 V	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V	0-1 V	11-14 V
Soft top bow raised	11-14 V	0-1 V	11-14 V	11-14 V	11-14 V	0-1 V	0-1 V	0-1 V	11-14 V	0-1 V	11-14 V
Soft top compartment cover open	11-14 V	0-1 V	11-14 V	11-14 V	11-14 V	0-1 V	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V
Soft top bow lowered	11-14 V	0-1 V	11-14 V	0-1 V	11-14 V	11-14 V	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V
Soft top open	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V	11-14 V	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V
Soft top compartment cover locked	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V	0-1 V	11-14 V
Roll-over bar extended	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V	11-14 V	0-1 V
Soft top locked at front	0-1 V	11-14 V	0-1 V	0-1 V	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V	11-14 V	0-1 V

Soft top closing sequence

Limit switches actuated	Soft top			Soft top bow			Soft top compartment cover			Roll-over bar	
	locked	up	open	down	locked	open	closed	locked	open	retracted	extended
	S84/1 S84/2	S84/4	S84/3	S84/7	S84/8	S84/6	A25/1s1	A25/1s2	S84/5	S83/5	S83/6
Socket box, connection schematic Y (□22, fig. 5) Control unit in diagnosis mode □22	Y 5 └┬ 6	Y 7	Y 9	Y 10	Y 11	Y 12	Y 13	Y 14	Y 15	Y 16	Y 17
Soft top unlocked at front, roll-over bar extended	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V	11-14 V	0-1 V
Roll-over bar retracted	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V	0-1 V	11-14 V
Soft top compartment cover open	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V	11-14 V	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V
Soft top closed, soft top bow lowered	11-14 V	0-1 V	11-14 V	0-1 V	11-14 V	11-14 V	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V
Soft top bow raised	11-14 V	0-1 V	11-14 V	11-14 V	11-14 V	0-1 V	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V
Soft top compartment cover locked	11-14 V	0-1 V	11-14 V	11-14 V	11-14 V	0-1 V	0-1 V	0-1 V	11-14 V	0-1 V	11-14 V
Soft top bow lowered	11-14 V	0-1 V	11-14 V	0-1 V	11-14 V	11-14 V	0-1 V	0-1 V	11-14 V	0-1 V	11-14 V
Soft top bow locked	11-14 V	0-1 V	11-14 V	0-1 V	0-1 V	11-14 V	0-1 V	0-1 V	11-14 V	0-1 V	11-14 V
Soft top locked at front	0-1 V	0-1 V	11-14 V	0-1 V	0-1 V	11-14 V	0-1 V	0-1 V	11-14 V	0-1 V	11-14 V

Test program - Electrical system

Testing

Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 1.0	Soft top control unit (N52) Power supply Terminals 30, 15	 	Ignition: ON	11-14 V 11-14 V	⇒ 1.1 Terminal 31
⇒ 1.1	Power supply Terminals 30, 15	 	Ignition: ON	11-14 V 11-14 V	Terminal 30 Terminal 15
⇒ 2.0	Hydraulic unit switching circuit (A7/5) Power supply	 	Disconnect plug connection (A7/5x1).	11-14 V 11-14 V	Wiring

Test program - Electrical system

Testing




Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ [2.0]			Ignition: ON Open front catches Actuate soft top actuating switch (S84) in direction open or close	0-1 V 11-14 V Hydraulic unit (A7/5m1) running	⇒ 18.0 ⇒ 18.0 ⇒ 21.0 ⇒ 2.1 Relay (A7/5k1) Wiring
⇒ 2.1	A7/5m1		Disconnect A7/5k1 Bridge sockets 1 and 3 in connector A7/5k1	A7/5m1 running	Wiring A7/5m1
⇒ 3.0	Operating time exceeded		Reset pulse display	Pulse display !	Control unit (N52)
⇒ 4.0	Limit switch signals not logical		Check limit switch signals according to table (□24).		Wiring Limit switches

Test program - Electrical system




Testing

Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 5.0	Circuit, soft top compartment cover switch "locked" (A25/1s2) Power supply		Control unit (N52) in diagnosis mode □22 Soft top compartment cover locked unlocked	0-1 V 11-14 V	⇒ 5.1 ⇒ 5.1
⇒ 5.1	A25/1s2 Resistance		Ignition: OFF Disconnect test cable (Y) from control unit (N52) Soft top compartment cover locked unlocked	0-5 Ω >20 k Ω	A25/1s2 Wiring Nominal values okay: N52
⇒ 6.0	Circuit, soft top compartment cover switch "closed" (A25/1s1) Power supply		Control unit (N52) in diagnosis mode □22 Soft top compartment cover closed open	0-1 V 11-14 V	⇒ 6.1 ⇒ 6.1



Test program - Electrical system Testing

Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 6.1	B A25/1s1 Resistance		Ignition: OFF Disconnect test cable (Y) from control unit (N52) Soft top compartment cover	closed open 0-5 Ω >20 k Ω	A25/1s1 Wiring Nominal values okay: N52
⇒ 7.0	7 Circuit, soft top compartment "open" switch (S84/5) Power supply		Control unit (N52) in diagnosis mode <input type="checkbox"/> 22 Soft top compartment cover	open closed 0-1 V 11-14 V	⇒ 7.1 ⇒ 7.1
⇒ 7.1	7 S84/5 Resistance		Ignition: OFF Disconnect test cable (Y) from control unit (N52) Soft top compartment cover	open closed 0-5 Ω >20 k Ω	S84/5 Wiring Nominal values okay: N52

Test program - Electrical system Testing

Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 8.0	B Circuit, soft top bow "locked" switch (S84/8) Power supply		Control unit (N52) in diagnosis mode <input type="checkbox"/> 22 Soft top bow	locked unlocked 0-1 V 11-14 V	⇒ 8.1 ⇒ 8.1
⇒ 8.1	B S84/8 Resistance		Ignition: OFF Disconnect test cable (Y) from control unit (N52) Soft top bow	locked unlocked 0-5 Ω >20 k Ω	S84/8 Wiring Nominal values okay: N52
⇒ 9.0	9 Circuit, soft top bow "lowered" switch (S84/7) Power supply		Control unit (N52) in diagnosis mode <input type="checkbox"/> 22 Soft top bow	down up 0-1 V 11-14 V	⇒ 9.1 ⇒ 9.1 N52




Test program - Electrical system Testing

Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 9.1	9 S84/7 Resistance		Ignition: OFF Disconnect test cable (Y) from control unit (N52) Soft top bow	down up 0-5 Ω >20 k Ω	S84/7 Wiring Nominal values okay: N52
⇒ 10.0	10 Circuit, soft top bow "raised" switch (S84/6) Power supply		Control unit (N52) in diagnosis mode <input type="checkbox"/> 22 Soft top bow	up down 0-1 V 11-14 V	⇒ 10.1 ⇒ 10.1
⇒ 10.1	10 S84/6		Ignition: OFF		S84/6




up
down

0-5 Ω
>20 k Ω




Test program - Electrical system Testing

Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 11.0 II	Circuit, left front soft top "locked" switch (S84/1) Power supply		Control unit (N52) in diagnosis mode □22 Soft top, front	locked 0-1 V unlocked 11-14 V	⇒ 11.1 ⇒ 11.1
⇒ 11.1 II	S84/1 Resistance		Ignition: OFF Disconnect test cable (Y) from control unit (N52) Soft top, front	locked 0-5 Ω unlocked >20 k Ω	S84/1 Wiring Nominal values okay: N52
⇒ 12.0 I2	Circuit, right front soft top "locked" switch (S84/2) Power supply		Control unit (N52) in diagnosis mode □22 Soft top, front	locked 0-1 V unlocked 11-14 V	⇒ 12.1 ⇒ 12.1

Test program - Electrical system Testing




Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 12.1 I2	S84/2 Resistance		Ignition: OFF Disconnect test cable (Y) from control unit (N52) Soft top, front	locked 0-5 Ω unlocked >20 k Ω	S84/2 Wiring Nominal values okay: N52
⇒ 13.0 I3	Circuit, soft top "open" switch (S84/3) Power supply		Control unit (N52) in diagnosis mode □22 Soft top	open 0-1 V closed 11-14 V	⇒ 13.1 ⇒ 13.1
⇒ 13.1 I3	S84/3 Resistance		Ignition: OFF Disconnect test cable (Y) from control unit (N52) Soft top	open 0-5 Ω closed >20 k Ω	S84/3 Wiring Nominal values okay: N52

Test program - Electrical system Testing



Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 14.0 I4	Circuit, soft top "up" switch (S84/4) Power supply		Control unit (N52) in diagnosis mode □22 Soft top	closed 0-1 V open 11-14 V	⇒ 14.1 ⇒ 14.1
⇒ 14.1 I4	S84/4 Resistance		Ignition: OFF Disconnect test cable (Y) from control unit (N52) Soft top	closed 0-5 Ω open >20 k Ω	S84/4 Wiring Nominal values okay: N52
⇒ 15.0 I5	Circuit, roll-over bar		Control unit (N52) in diagnosis mode □22		

retracted 0-1 V ⇒ 15.1
 extended 11-14 V ⇒ 15.1





Test program - Electrical system Testing

Test step Pulse display	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 15.1 5	S83/5 Resistance		Ignition: OFF Disconnect test cable (Y) from control unit (N52) Roll-over bar	retracted 0-5 Ω extended >20 k Ω	S83/5 Wiring Nominal values okay: N52
⇒ 16.0 6	Circuit, roll-over bar "extended" switch (S83/6) Power supply		Control unit (N52) in diagnosis mode □22 Roll-over bar	extended 0-1 V retracted 11-14 V	⇒ 16.1 ⇒ 16.1
⇒ 16.1 6	S83/6 Resistance		Ignition: OFF Disconnect test cable (Y) from control unit (N52) Roll-over bar	extended 0-5 Ω retracted >20 k Ω	S83/6 Wiring Nominal values okay: N52

Test program - Electrical system Testing

Test step Pulse display	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 17.0 7	Roll-over bar Crash actuation		Ignition: OFF, ON Press roll-over bar convenience switch (S83) in direction extend (approx. 10 s). Retract roll-over bar with switch (S83)	Roll-over bar is retracted	Crash actuation has been tripped
⇒ 18.0 8	Circuit, soft top switch (S84) Power supply	 	Ignition: ON Press S84 in direction close Ignition: ON Press S84 in direction open	11-14 V 0-1 V 11-14 V 0-1 V	⇒ 18.1

Test program - Electrical system Testing

Test step Pulse display	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 18.1 8	S84 Resistance	 	Disconnect test cable (Y) from control unit (N52). Press S84 to: non-actuated position Press in direction close Non-actuated position Press in direction open	>20 k Ω 0-5 Ω >20 k Ω 0-5 Ω	Wiring S84 Nominal values okay: N52
⇒ 19.0 9	Speed signal		Drive vehicle (approx. 40 km/h)	approx. 6 V ~	Wiring Hall sensor (B6) Plug connection/Hall-effect sensor (X53/5)
⇒ 20.0	Circuit, roll-over bar convenience switch (S83) and roll-over bar switch (rear) (S83/4)		Ignition: ON Rear power window safety switch (S21/7) in unlocked	11-14 V	⇒ 20.1 ⇒ 20.2

Test program - Electrical system Testing

Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ [20.0]			Press S83 in direction extend roll-over bar Press S83/4 in direction extend roll-over bar S83 and S83/4 in: Non-actuated position Press S83 in direction retract roll-over bar Press S83/4 in direction retract roll-over bar	0-1 V 0-1 V 11-14 V 0-1 V 0-1 V	⇒ 20.1 ⇒ 20.2 ⇒ 22.0 ⇒ 20.1 ⇒ 20.2 ⇒ 20.1 ⇒ 20.2 ⇒ 22.0
⇒ 20.1	S83 Resistance		Ignition: OFF Disconnect test cable (Y) from control unit S83 and S83/4 in: Non-actuated position Press S83 in direction extend roll-over bar	>20 k Ω 0-5 Ω	Wiring S83 S83/4

Test program - Electrical system Testing




Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ [20.1]			S83 and S83/4 in: Non-actuated position Press S83 in direction retract roll-over bar	>20 k Ω 0-5 Ω	Wiring S83 S83/4 Nominal values okay: control unit (N52)
⇒ 20.2	S83/4 Resistance		Ignition: OFF Disconnect test cable (Y) from (N52) S83 and S83/4 in: Non-actuated position Press S83/4 in direction extend roll-over bar	>20 k Ω 0-5 Ω	Wiring S83 S83/4 Nominal values okay: N52
			S83 and S83/4 in: Non-actuated position Press S83/4 in direction retract roll-over bar	>20 k Ω 0-5 Ω	

Test program - Electrical system Testing





Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 21.0	Circuit, solenoid valve, retract roll-over bar (Y57y10) Power supply		Ignition: ON Actuate roll-over bar with switch (S83) as follows retract extend	0-1 V 11-14 V 11-14 V	S83 Control unit (N52) ⇒ 21.1 ⇒ 21.1
⇒ 21.1	Y57y10 Resistance		Disconnect test cable (X) from control unit (N52)	10-20 Ω	Wiring Y57y10 Relay (A7/5k1) Nominal values okay: N52
⇒ 22.0	Circuit, rear power window safety switch (S21/7) Power supply		Ignition: ON Hold switch (S83/4) down in position extend roll-over bar S21/7 in position:		

				unlocked	0-1 V	Wiring ⇒ 22.1 ⇒ 20.0
--	--	--	--	----------	-------	----------------------------

Test program - Electrical system Testing


Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 22.1	S21/7 Resistance		Ignition: OFF Disconnect test cable (Y) from control unit (N52) Hold S83/4 down in position extend roll-over bar S21/7 in position:	unlocked 0-5 Ω locked >20 k Ω	Wiring S21/7 Nominal values okay: N52
⇒ 23.0	Circuit, solenoid valve, extend roll-over bar (Y57y11) Power supply		Ignition: ON Actuate roll-over bar with switch (S83) as follows	extend 11-14 V retract 0-1 V	⇒ 23.1 Control unit (N52)
⇒ 23.1	Y57y11 Resistance		Disconnect test cable (Z) from (N52)	5-15 Ω	Wiring Y57y11 Nominal value okay: N52




Test program - Electrical system Testing

Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 24.0	Circuit, hydraulic unit main valve (A7/5y1) ¹⁾ Power supply		Ignition: ON Open front catches Actuate soft top actuating switch (S84) in direction open or close Roll-over bar retracted	0-1 V 10-14 V	Control unit (N52) ⇒ 24.1
⇒ 24.1	A7/5y1 Resistance		Disconnect test cable (Z) from control unit	5-15 Ω	Wiring A7/5y1 Nominal value okay: N52
⇒ 25.0	Circuit, solenoid valve, soft top compartment cover lock (Y56y3) Power supply		Ignition: ON Actuate soft top compartment cover with soft top actuating switch (S84) as follows:	unlock 10-14 V lock 0-1 V	⇒ 25.1 Control unit (N52)
⇒ 25.1	Y56y3 Resistance		Disconnect test cable (X) from control unit	5-15 Ω	Wiring Y56y3 Nominal value okay: Y56y3 sticks mechanically or N52





1) Hydraulic unit main valve (A7/5y1) eliminated as of chassis number 124 061-1B-837708

Test program - Electrical system Testing




Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 26.0	Circuit, solenoid valve, soft top bow lock (Y56y4), soft top compartment cover		Ignition: ON Actuate soft top bow with soft top actuating switch		


			unlock	10-14 V	⇒ 26.1
			lock	0-1 V	Control unit (N52)
⇒ 26.1	Y56y4 Resistance		Disconnect test cable (X) from N52	5-15 Ω	Wiring Y56y4 Nominal value okay: Y56y4 sticks mechanically or N52
⇒ 27.0	Circuit, solenoid valve, soft top compartment cover drive (Y56y5) open Power supply		Ignition: ON Actuate soft top compartment cover with soft top actuating switch (S84) as follows:		
			raise	10-14 V	⇒ 27.1
			lower	0-1 V	Control unit (N52)
⇒ 27.1	Y56y5 Resistance		Disconnect test cable (X) from N52	5-15 Ω	Wiring Y56y5 Nominal value okay: N52

Test program - Electrical system Testing





Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 28.0	Circuit, solenoid valve, soft top "open" (Y55y6) Power supply		Ignition: ON Actuate soft top with soft top actuating switch (S84) as follows:		
			open	10-14 V	⇒ 28.1
			close	0-1 V	Control unit (N52)
⇒ 28.1	Y55y6 Resistance		Disconnect test cable (X) from N52	5-15 Ω	Wiring Y55y6 Nominal value okay: N52
⇒ 29.0	Circuit, solenoid valve, soft top "closed" (Y55y7) Power supply		Ignition: ON Actuate soft top with soft top actuating switch (S84) as follows:		
			close	10-14 V	⇒ 29.1
			open	0-1 V	Control unit (N52)
⇒ 29.1	Y55y7 Resistance		Disconnect test cable (X) from N52	5-15 Ω	Wiring Y55y7 Nominal value okay: N52

Test program - Electrical system Testing


Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 30.0	Circuit, solenoid valve, soft top bow - raise (Y55y8) Power supply		Ignition: ON Actuate soft top bow with soft top actuating switch (S84) as follows:		
			raise	10-14 V	⇒ 30.1
			lower	0-1 V	Control unit (N52)
⇒ 30.1	Y55y8 Resistance		Disconnect test cable (X) from N52	5-15 Ω	Wiring Y55y8 Nominal value okay: N52
⇒ 31.0	Circuit, solenoid valve, soft top bow - lower (Y55y9) Power supply		Ignition: ON Actuate soft top bow with soft top actuating switch (S84) as follows:		
			lower	10-14 V	⇒ 31.1
			raise	0-1 V	Control unit (N52)

⇒ 31.1	Y55y9 Resistance		Disconnect test cable (X) from N52	5-15 Ω	Wiring Y55y9 Nominal value okay: N52
--------	---------------------	--	------------------------------------	--------	--

Test program - Electrical system Testing

Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 32.0	Combination relay (heated rear window, N10) Power supply		Soft top open	Indicator flashes (approx. 2 Hz)	Wiring Switch, soft top up (S84/4) Control unit (N52)
⇒ 33.0	Convenience control unit (N57) Power supply		Ignition: ON Press soft top actuating switch (S84) momentarily two times and then hold down: in direction open in direction close	0-1 V -9 to -14 V 11-14 V	Wiring Control unit (N52) N57
⇒ 34.0	Warning buzzer for soft top control unit		Ignition: ON	Gong sounds	Wiring Ceiling lamp with delay (E15)
⇒ 35.0	Indicator lamp, soft top actuating switch (S84) Power supply		Ignition: ON	11-14 V	Wiring

Test program - Electrical system Testing

Test step	Scope of test	Measuring instrument/ Test connection	Action/ Prerequisite	Nominal value	Possible cause/Remedy
⇒ 36.0	Indicator lamp control for soft top actuating switch (S84)		Soft top completely closed or open Ignition: ON	Indicator lamp should come on for approx. 1 s	Wiring S84 Control unit (N52)
⇒ 37.0	Roll-over bar crash-activated trigger unit (N53)		Ignition: ON	>2,4 V >2,4 V	Wiring Fault in roll-over bar system (Body, volume 3-19.1) Roll-over bar crash-activated trigger unit (N53)

Test program - Electrical system Testing