
MODEL 202, 208, 210

with CODE (580)Air conditioning or, for USA, Tempmatic with CODE (581a) Automatic air conditioning

Models 202, 208

Ilustrated on model 202 with Tempmatic air conditioning

- 1 Pressure line
- 2 Pressure line
- 3 Receiver/drier
- 4 Clamping strap with retaining lugs
- B12 Refrigerant pressure sensor



P83.30-0235-04

Models 202, 208 Illustrated on model 202 with automatic air conditioning


- Pressure line
 Pressure line
 Receiver/drier
- 4 Clamping strap with retaining lugs
- B12 Refrigerant pressure sensorB12/1 Refrigerant temperature sensor

P83.30-0700-04

Model 210

FIG. A	illustrated with Tempmatic all
	conditioning (TAC)
Fig. B	Illustrated with automatic air
	conditioning (AAC)

- Pressure line
 Pressure line
 Receiver/drier
- 4 Clamping strap with retaining lugs B12 Refrigerant pressure sensor B12/1 Refrigerant temperature sensor



P83.30-0346-06

Revisions

12.8.97	Safety note added	

X	Removal, installation	

⚠ Danger!	Explosion hazard when performing welding or brazing work on closed air conditioning. Poisoning hazard from inhaling overheated refrigerant vapors. Injury hazard from eye or skin contact with liquid refrigerant	Never perform welding or brazing work on the closed air conditionig system or in its vicinity. Smoking and open flame is prohibited. Wear protective goggles and protective gloves, work only in well ventilated rooms. Perform repair work on air conditioning circuit only if system is discharged.	AS83.00-Z-0001-01A
(3)	Action to be taken in the event air conditioning is damaged or leaks	-	AH83.30-N-0004-01A
(3)	Protect air conditioning circuit and components from moisture during repair work	All models with air conditioning	AH83.30-N-0005-01A
(3)	In the event of malfunctions to the air conditioning, resulting from leakage, contamination or icing up always install new receiver/drier (3) when replacing or repairing A/C compressor.		
i	Notes on handling R134a refrigerant	All models with R134a refrigerant	AH83.30-N-0003-01A
1	Drain air conditioning (recycle), evacuate, charge, check for leakage	Add quantity of compressor oil evacuated to refrigeration circuit when charging air conditionining	
2	Disconnect refrigerant pressure sensor connector (B12)		
3	Unscrew refrigerant pressure sensor (B12)	i On model 202 as of September 1995, 208, 210 with automatic air conditioning, also unscrew refrigerant temperature sensor (B12/1) i Installation: When installing moisten thread with compressor oil	
4	Disconnect lines (1 and 2) from receiver/drier	I Plug openings (parts kit) I Installation: When installing lines, moisten threads with compressor oil	*BA83.30-P-1003-01A
5	Unscrew screws (arrows)	•	
6	Remove receiver/drier (3)	On vehicles with code 480 level control position oil supply reservoir to side	
7	Loosen clamping strap (4) with retaining lugs and pull off		
8	Reinstall in opposite order	i Observe quantity of oil to be added when replacing receiver/drier	*BF83.55-P-1005-01A
9	Switch on air conditioning and allow it to idle for approx. 4 minutes	i Set temperature dials to blue or automatic acconditioning to "Lo" Blower to max.	r
10	Check air conditioning for proper function	i Air outlet temperature at center nozzle should not drop below +5 °C, if necessary, Perform diagnosis according to Diagnosis Manu	al
11	Find leaky point in air conditioning circuit		*WH58.30-Z-1001-27A

Nm Air conditioning

Ni	umber	Designation	Model 202	Model 210	Model 208
ВА	A83.30-P-1003-01A	Lines on receiver/drier Nm	17	17	17

A/C compressor

Number	Designation	A/C compressor 7SB16 on models 140, 170, 202, 208, 210
--------	-------------	-----------------------------------------------------------------

BF83.55-P-1005-01A	Additional oil filling capacity when replacing receiver/drier	Compresor oil	cm3	10
		Specifications for	She	&.2.(BB00.40-P-
		service products	et	0362-00A)

Commercially available tools (see Workshop Equipment Manual)

Number	Designation	Company (e. g.	Order number
WH58.30-Z-1001-27A	Air conditioning leak detector	Behr GmbH u. Co. KG	988 047
		70469 Stuttgart	Model 5650