



Document number: pe46.10-p-2101-97dba
Document title: Wiring diagram for steering column module control unit

Code:	Designation:	Position:
A0	Use of wiring diagrams	88L
A45	Fanfare horns and airbag clock spring contact	23D
A45	Fanfare horns and airbag clock spring contact	37D
A45	Fanfare horns and airbag clock spring contact	46D
Code 238	Active Lane Keeping Assist	40H
Code 243	Active Lane Keeping Assist	5E
Code 421	9G-TRONIC	43H
Code 421	9G-TRONIC	62H
Code 443	Steering wheel heater	23H
Code 443	Steering wheel heater	47H
Code 443	Steering wheel heater	70A
Code 443	Steering wheel heater	70A
Code 443	Steering wheel heater	5E
Code 460	Canada version	79A
Code 494	USA version	79A
Code L	LEFT-HAND DRIVE	3G
Code L	LEFT-HAND DRIVE	9G
Code L	LEFT-HAND DRIVE	56L
Code L	LEFT-HAND DRIVE	52L
Code R	RIGHT-HAND DRIVE	3G
Code R	RIGHT-HAND DRIVE	9G
Code R	RIGHT-HAND DRIVE	52L
Code R	RIGHT-HAND DRIVE	56L
Flex E	Chassis FlexRay	12K
K40/6	Driver-side fuse and relay module	3L
K40/6	Driver-side fuse and relay module	9L
K40/6f205	Fuse 205	2L
K40/6f211	Fuse 211	7L
M99	Steering wheel vibration motor	42L
N135	Steering wheel electronics	26E
N135	Steering wheel electronics	33E
N135	Steering wheel electronics	40E
N135	Steering wheel electronics	46E
N135	Steering wheel electronics	49E
N135	Steering wheel electronics	57E
N135	Steering wheel electronics	65E
N135s1	Left upper horn button	38L
N135s2	Right upper horn button	39L
N135s3	Left lower horn button	40L
N2/10	Supplemental restraint system control unit	17L
N49	Steering wheel angle sensor	74B
N80	Steering column module control unit	4A
N80	Steering column module control unit	12A
N80	Steering column module control unit	20A
N80	Steering column module control unit	29A
N80	Steering column module control unit	37A
N80	Steering column module control unit	46A
N80	Steering column module control unit	54A
N80	Steering column module control unit	62A
N80	Steering column module control unit	77A
N80	Steering column module control unit	82A
N80	Steering column module control unit	69A
R12/13	Driver airbag squib 1	20L
R12/14	Driver airbag squib 2	21L
R22/4	Steering wheel heater	26L
R22/4	Steering wheel heater	49L
R22/4b1	Heating element temperature sensor	27L

Document number: pe46.10-p-2101-97dba
Document title: Wiring diagram for steering column module control unit


Code:	Designation:	Position:
R22/4r1	Steering wheel heater heating element	25L
S110/1	Steering wheel downshift button	46L
S110/1	Steering wheel downshift button	65L
S111/1	Steering wheel upshift button	44L
S111/1	Steering wheel upshift button	64L
S16/13	DIRECT SELECT lever	82D
S163/1	Instrument cluster multifunction steering wheel button group	30L
S163/1	Instrument cluster multifunction steering wheel button group	53L
S163/1	Instrument cluster multifunction steering wheel button group	57L
S163/1s10	Instrument cluster finger navigation pad	30L
S163/1s11	Volume control button	31L
S163/1s13	"Back" button	32L
S163/1s9	Mute function button	29L
S163/2	Head unit multifunction steering wheel button group	35L
S163/2	Head unit multifunction steering wheel button group	57L
S163/2	Head unit multifunction steering wheel button group	53L
S163/2s10	Head unit finger navigation pad	34L
S163/2s13	"Back" button	37L
S163/2s3	Accept/terminate phone call button	35L
S163/2s4	Voice control system ON button	36L
S4	Combination switch	68D
S4/2	Horns contact plate	61L
S40/4	Cruise control lever	77D
S40/4r1	DISTRONIC control	81D
S40/4s1	Resume from memory switch	75D
S40/4s2	Decelerate and set switch	76D
S40/4s3	Accelerate and set switch	77D
S40/4s4	OFF switch	78D
S40/4s6	Variable speed limiter switch	80D
S40/4v1	Variable speed limiter light-emitting diode	80D
S4s1	Turn signal lamps switch	67D
S4s2	Headlamp flasher/high beam switch	68D
S4s4	Windshield washer system switch	69D
S4s5	Wipe switch	69D
S59	Steering column adjustment switch	71D
S59/1	Steering column adjustment and steering wheel heater switch	71D
S59/1e1	Steering wheel heater indicator lamp	71D
W34	Left footwell ground point	9G
W34	Left footwell ground point	4G
W34/3	Right footwell ground point	9G
W34/3	Right footwell ground point	4G






Cut here

▼ Affix page 3 here ▼



Cut here

▼ Affix page 4 here ▼



Cut here