

<b>Code:</b>	<b>Designation:</b>	<b>Position:</b>
1	Drivetrain operational, signal	18D
10	Steering diagnosis, communication	
10	Steering diagnosis, communication	
10	Steering diagnosis, communication	
11	Steering assistance, request	9F
11	Steering assistance, request	17F
12	Speed, turn rate and lateral acceleration, signal	4K
12	Speed, turn rate and lateral acceleration, signal	9F
12	Speed, turn rate and lateral acceleration, signal	17G
13	Steering angle, signal	9F
13	Steering angle, signal	17C
14	Steering wheel velocity, signal	17C
14	Steering wheel velocity, signal	10F
14	Steering wheel velocity, signal	17C
15	Parking system control unit, status	
16	Electrical power steering control unit, status	
17	Toothed rack position, signal	
18	Toothed rack position, request	
19	Vehicle stop, signal	
2	Wheel speed, signal	7K
2	Wheel speed, signal	7F
2	Wheel speed, signal	17F
4	Engine speed, signal	
5	Torque sensor, signal	6G
6	Engine running, signal	
7	Power steering, actuation	9J
8	Instrument cluster, message	6C
9	Circuit 15, status	18E
9	Circuit 15, status	8F
9	Circuit 15, status	5B
A1	Instrument cluster	20J
A8/1	Transmitter key	
A91	Electric power steering electromechanical controller unit	9G
A91b1	Electric power steering torque sensor	9H
A91b1	Electric power steering torque sensor	6E
A91m1	Electric power steering actuator motor	9H
A91m1	Electric power steering actuator motor	4E
B24/15	Yaw rate, lateral and longitudinal acceleration sensor	1H
CAN D	Diagnostic CAN	14E
CAN E1	Chassis CAN 1	19E
CAN E1	Chassis CAN 1	18G

Code :	Designation :	Position :
CAN E1	Chassis CAN 1	14B
CAN E1	Chassis CAN 1	14L
CAN E2	Chassis CAN 2	5D
CAN E2	Chassis CAN 2	14F
CAN E2	Chassis CAN 2	3F
CAN H	Vehicle dynamics CAN	3K
Code 235	Active Park Assist	1A
L6/1	Left front axle rpm sensor	10K
L6/2	Right front axle rpm sensor	10K
L6/3	Left rear axle rpm sensor	10K
L6/4	Right rear axle rpm sensor	10K
N10/1	Front SAM control unit with fuse and relay module	16D
N3/10	ME-SFI [ME] control unit	22B
N3/9	CDI control unit	22E
N30/4	Electronic Stability Program control unit	5J
N30/6	Regenerative braking system control unit	5J
N30/7	Premium Electronic Stability Program control unit	5J
N49	Steering angle sensor	10B
N62	Parking system control unit	2B
N68	Electrical power steering control unit	5E
N73	Electronic ignition switch control unit	19H
N80	Steering column module control unit	9B
U74	Valid for diesel engines	21E
U75	Valid for gasoline engines	21B
U938	Valid for ESP Basic	4J
U939	Valid for ESP Premium	4J
U968	Valid for mild hybrid drive	4J
X11/4	Diagnostic connector	11D

