


ENGINES 272, 273 in MODEL 212

- 1 Front engine cover
 2 Engine air intake duct
 3 Hose
 4 Air cleaner housing
 4a Mount
 6 Gasket



P09.10-2232-06

☒ ☒	Remove/install		
1	Pull off the front engine cover (1) from above.	i Installation: Check for correct seating of front engine cover (1) on the air filter housing (4).	
2	Remove left and right engine air intake duct (2) upstream of air filter	☑ Check left and right engine air intake duct (2) for damage and replace if necessary.	
3	Detach hose (3) for air pump at air filter housing (4)	If necessary i Installation: The arrows on the hose (3) and the air filter housing (4) must point towards each other.	
4	Pry clamp off air filter housing (4)	If necessary	
5	Detach air filter housing (4) upwards from mounts (4a) on left and right cylinder head cover	⚠ In order to avoid scratches and damage, the air filter housing (4) must be put down on a padded base. i Installation: Apply lubricant to support (4a) on the left and right cylinder head cover and the seal (6) on the air filter housing (4) using a suitable tool. i Installation: Press air filter housing (4) evenly into supports (4a) and pay attention to correct seat of seal (6) in the air filter housing (4) and on hot film mass air flow sensor. The gap between air filter housing (4) and seal (6) must be even and closed. Antifriction agent	*BR00.45-Z-1010-06A
6	Install in the reverse order		

Repair materials

Number	Designation	Order number
BR00.45-Z-1010-06A	Lubricant, rubber assembly 1 l	A 000 989 03 67