


AR42.10-P-1700-02W	Move rear axle brakepads into assembly position		
--------------------	---	--	--

Model 117, 156, 166, 172, 176, 190, 205, 242, 246, 253, 292
Model 217, 222, 231

Move to assembly position (via the workshop menu in the instrument cluster)
Shown on model 172



P42.10-3094-11

1 Turn ignition lock to position "15R".

i The "Trip" menu item must show the trip and kilometer reading.

2 Close hood.

If the multifunction display (1) shows the message "Engine hood open".

3 Release parking brake.

4 First press the "Accept phone call" button (6) and hold it down, then within 1 s also press the "OK" button (3) and hold it down.

i After approx. 5 s, the multifunction display (1) shows the Workshop menu with the tabs "Vehicle data", "Dynamometer test", "Brakepad replacement" and "ASSYST PLUS".

5 Press button (4) repeatedly until "Brakepad replacement" is highlighted, and confirm selection with "OK" button (3).

i The multifunction display (1) then shows "Move to assembly position".

6 Confirm with "OK" button (3).

7 Switch off ignition.

i This prevents the assembly position from being exited unintentionally.

Exit assembly position (via the workshop menu in the instrument cluster)

! Leave the assembly position only with the brakepads fitted and the brake caliper installed. Otherwise the brake piston will be pushed out of the brake caliper.

8 Turn ignition lock to position "15R".

i The multifunction display (1) then shows "Assembly position reached/Exit assembly position".


9 Confirm with "OK" button (3).

i "Exiting assembly position" is shown in the multifunction display (1) for the duration of the assembly position exit. When the process has finished, the "Assembly position exited" indicator appears in the multifunction display (1).


10 Confirm with "OK" button (3).

i The multifunction display (1) shows the workshop menu with the "Vehicle data", "Dynamometer test", "Change brake lining" and "ASSYST PLUS" tabs.

11 Exit workshop menu with "Back" button (2).

 Do not depress the service brake during "Move to assembly position". Otherwise, the spindle in the brake caliper can be damaged.

12 Switch off ignition.

 The multifunction display (1) then shows "Assembly position reached".