
## AR13.20-P-0001GZA Remove/install belt drive components ENGINES 272, 273 in MODEL 164, 251

- 2 Poly-V-belt
- 2a Hexagon
- 2b Bolts
- 3 Tensioner pulley
- 4 Poly-V belt tensioning device
- 5 Guide pulleys



P13.22-2121-06

X	Removing		
⚠ Danger!	Risk of injury caused by moving parts that	No parts of the body or limbs should be within	AS00.00-Z-0009-01A
	can <b>pinch, crush</b> or, in extreme cases, even <b>sever</b> extremities	the operating range of the mechanism when moving components.	
1	Remove front engine cover		
2	Detension poly-V belt (2), remove and detension tensioner pulley (3)	i To do this use a hexagon (2) on the poly-V belt tensioning device (4).	
4	Checking		
3	Check profile of belt pulley and poly-V belt tensioning device (4) for damage and soiling		
4	Check poly-V belt (2) for wear and damage and replace if necessary		
₩ AP	Check visible area of poly-V belt for wear	Model 164.1 with engine 272.9, 164.8 with engine 273.9	AP13.22-P-1352GZC
₩ AP		Model 251.065/ 165	AP13.22-P-1352RTC
		Model 164.1 with engine 273.9, 251.054/ 056/ 072/ 154/ 156/ 172	
XX	Remove/install	Only perform steps 5 through 9 for remove/ install of poly-V belt tensioning device (4).	
5	Remove electric fan	Model 164 with engine 273	AR20.40-P-5000GZA
6	Lock poly-V belt tensioning device (4)	<b>i</b> Swivel poly-V belt tensioning device (4) at hexagon (2a) in an anti-clockwise direction and lock in place using drift (03).	
7	Remove bolts (2b) and poly-V belt tensioning device (4)	Nm	*BA13.25-P-1001-01P
8	Unclamp poly-V belt tensioning device (4)	When replacing poly-V belt tensioning device (4) <b>i</b> Clamp poly-V belt tensioning device (4) in a vise, swivel at hexagon (2a) in an anti- clockwise direction, pull out drift (03) and slacken poly-V belt tensioning device (4). <b>i</b> Installation: The poly-V belt tensioning device (4) can only be installed when locked.	
9	Install in the reverse order		
XX	Remove/install	Only perform steps 10 through 12 for remove/ install of guide pulleys (5).	
10	Remove covers for guide pulleys (5)		
11	Remove bolts to guide pulleys (5) from coolant pump and take off	Nm	*BA20.10-P-1004-01U
12	Install in the reverse order		
X	Install		

	and tension	<ul> <li>I To do this use a hexagon (2) on the poly-V A belt tensioning device (4).</li> <li>IDo not use wax or similar products, as this may cause poly-V belt (2) to slip.</li> </ul>	R13.22-P-3902-02VA
14	Fit front engine cover		

## <sup>Nm</sup> Belt tensioning device

Number			Engine 272	Engine 273
BA13.25-P-1001-01P	Bolt from poly-V belt tensioning device to timing case cover	Nm	35=26 ft.	35

## Nm Coolant pump, coolant thermostat

Number	Designation			Engine 272	Engine 273
BA20.10-P-1004-01U	Bolt, guide pulley between water pump and belt tensioner	Initial installation	Nm	35 <b>=</b> 26 f	35
		Follow-up operations	Nm	25 <sub>=18</sub> ft.	25