

Code:	Designation:	Position:
A0	Color code key	80A
A2/30	Navigation module	40L
A2/30-1	Cradle for navigation module	37K
A40/11	Multifunction camera	35L
A40/13	Stereo multifunction camera	35L
A40/8	Audio/COMMAND display	20L
A40/9	Audio/COMMAND control panel	13L
A40/9x1	Audio/COMMAND control panel electrical connector	12H
Code 407	Start/stop voltage dip protection	16
Code 505	Radio 20 NT65, non-navigation-capable	42G
Code 508	Navigation module preinstallation	37G
Code 509	Navigation module	37G
Code 522	Audio 20 radio	42G
Code 531	COMMAND APS	42G
Code B03	ECO start/stop function	16
Code MEC4	Hybrid drive 20 KM VARIANT	1H
F32	Front electrical prefuse box	5L
F32T154	Prefuse 154	2K
F32T156	Prefuse 156	3K
F32T157	Prefuse 157	2K
F32T162	Prefuse 162	3K
M33	Electric air pump	24L
MA/13	COMMAND fan motor	44L
N10/1	Front SAM control unit with fuse and relay module	4A
N10/1	Front SAM control unit with fuse and relay module	12A
N10/1	Front SAM control unit with fuse and relay module	19A
N10/1	Front SAM control unit with fuse and relay module	29A
N10/1	Front SAM control unit with fuse and relay module	36A
N10/1	Front SAM control unit with fuse and relay module	44A
N10/1	Front SAM control unit with fuse and relay module	52A
N10/1	Front SAM control unit with fuse and relay module	61A
N10/1	Front SAM control unit with fuse and relay module	71A
N10/1f11	Fuse 11	20A
N10/1f13	Fuse 13	10A
N10/1f23	Fuse 23	48A
N10/1f32	Fuse 32	29A
N10/1KP	Secondary air injection relay	24A
N10/2	Rear SAM control unit with fuse and relay module	49L
N3/10	ME-SFI [ME] control unit	26L

Code:	Destination:	Position:
N3/10	ME-SFI [ME] control unit	31L
N3/10	ME-SFI [ME] control unit	52L
N3/10	ME-SFI [ME] control unit	56L
N3/9	CDI control unit	53L
N3/9	CDI control unit	64L
N3/9	CDI control unit	60L
N80	Steering column module control unit	9L
U1018	Valid for gasoline engine 276	736
U1027	Valid for gasoline engine 271 continuous fuel injection system (electronic)	296
U1027	Valid for gasoline engine 271 continuous fuel injection system (electronic)	516
U1027	Valid for gasoline engine 271 continuous fuel injection system (electronic)	726
U103	Valid for secondary air injection	226
U1032	Valid for engine 273 and 157	736
U1071	Valid for stereo multifunction camera	336
U1087	Valid for mono multifunction camera	336
U127	Valid for combustion engines 272 and 273 KE	256
U127	Valid for combustion engines 272 and 273 KE	696
U152	Valid for gasoline engine 156	296
U152	Valid for gasoline engine 156	666
U157	Valid for combustion engine 272 DE	716
U240	Valid for all except ECO start/stop function	16
U243	Valid for diesel engine 651 with all-wheel drive	586
U244	Valid for BlueTEC	636
U244	Valid for BlueTEC	636
U249	Valid for diesel engine 651 without all-wheel drive	586
U362	Valid for gasoline engine 274	736
U561	Valid for Delphi system	646
U562	Valid for Bosch system	646
U631	Valid for COMAND	136
U739	Valid for gasoline engine 271 DE	256
U739	Valid for gasoline engine 271 DE	546
U74	Valid for diesel engines	666
U74	Valid for diesel engines	476
U880	Valid for diesel engine 642	476
U880	Valid for diesel engine 642	516
U880	Valid for diesel engine 642	686
U897	Valid for intelligent servo module for DIRECT SELECT	136
U940	Valid without DIRECT SELECT	166
U948	Valid for diesel engine 651	486

Code:	Designation:	Position:
U948	Valid for diesel engine 651	586
U948	Valid for diesel engine 651	626
U948	Valid for diesel engine 651	626
U948	Valid for diesel engine 651	686
W1W2	Right cylinder bank ground point (engine)	24H
X120	Radio fan electrical connector	43J
X138/1	Front center console electrical connector	15H
X18/35	Instrument panel and vehicle floor electrical connector	38H
X18/35	Instrument panel and vehicle floor electrical connector	45J
X26	Interior and engine wiring harness electrical connector	23H
X26	Interior and engine wiring harness electrical connector	73J
X26	Interior and engine wiring harness electrical connector	67J
X26	Interior and engine wiring harness electrical connector	68J
X26	Interior and engine wiring harness electrical connector	70J
X26	Interior and engine wiring harness electrical connector	71J
X26	Interior and engine wiring harness electrical connector	74J
Z7/35	Circuit 87 Me connector sleeve	32H
Z7/35	Circuit 87 Me connector sleeve	64H
Z7/3521	Circuit 87 Me connector sleeve	60H
Z7/3521	Circuit 87 Me connector sleeve	49H
Z7/3521	Circuit 87 Me connector sleeve	73L
Z7/3821	Circuit 87 Mi connector sleeve	67L
Z7/3821	Circuit 87 Mi connector sleeve	71L
Z7/3822	Circuit 87 Mi connector sleeve	74L
Z7/521	Circuit 87 connector sleeve	70L
		68L

