



Code:	Designation:	Position:
A0	Color code key	121L
B12	Refrigerant pressure sensor	19L
B14	Outside temperature sensor	21L
CAN B	Interior CAN	90K
Code 580	Air conditioning	9J
Code 581	Automatic air conditioning	9J
Code 990	AMG vehicles	96B
E43/6	Center console ambience illumination	46L
E43/6	Center console ambience illumination	72L
E43/7	Driver-side instrument panel ambience illumination	32L
E43/7	Driver-side instrument panel ambience illumination	54L
E43/8	Passenger-side instrument panel ambience illumination	40L
E43/8	Passenger-side instrument panel ambience illumination	63L
F1/1	Fuse box	3L
H2	Left fanfare horn	3L
H2	Left fanfare horn	96L
H2/1	Right fanfare horn	100L
M5/1	Windshield washer system pump	97L
M5/1	Windshield washer system pump	103L
M5/2	Headlamp cleaning system pump	108L
N10/1	Front SAM control unit with fuse and relay module	112L
N10/1	Front SAM control unit with fuse and relay module	20A
N10/1	Front SAM control unit with fuse and relay module	5A
N10/1	Front SAM control unit with fuse and relay module	43A
N10/1	Front SAM control unit with fuse and relay module	52A
N10/1	Front SAM control unit with fuse and relay module	85A
N10/1	Front SAM control unit with fuse and relay module	92A
N10/1	Front SAM control unit with fuse and relay module	100A
N10/1	Front SAM control unit with fuse and relay module	13A
N10/1	Front SAM control unit with fuse and relay module	36A
N10/1	Front SAM control unit with fuse and relay module	60A
N10/1	Front SAM control unit with fuse and relay module	69A
N10/1	Front SAM control unit with fuse and relay module	76A
N10/1	Front SAM control unit with fuse and relay module	28A
N10/1	Front SAM control unit with fuse and relay module	108A
N10/1f31A	Fuse 31A	94A
N10/1f31B	Fuse 31B	95A
N10/1k0	Fanfare horn relay	97A
N30/4	Electronic Stability Program control unit	84L
N30/4	Electronic Stability Program control unit	84L

Code:	Designation:	Position:
N80/7	Premium Electronic Stability Program control unit	83L
N80/7	Premium Electronic Stability Program control unit	85L
S10/2	Right front brake wear sensor	88L
S10/2x1	Right front brake wear sensor electrical connector	88K
S10/2x1	Right front brake wear sensor	81L
S10/4	Right rear brake wear sensor electrical connector	80K
S10/4x1	Brake fluid level switch	16L
S11	Coolant level switch	17L
S41	Windshield washer system fluid level switch	28L
S42		246
U1028	Valid for engine 157	106A
U1028	Valid for engine 157	226
U1033	Not valid for engine 157	1028
U1033	Valid for left-hand drive vehicles	33J
U1033	Valid for left-hand drive vehicles	926
U12	Valid for left-hand drive vehicles	296
U12	Valid for left-hand drive vehicles	26J
U12	Valid for left-hand drive vehicles	56J
U12	Valid for left-hand drive vehicles	226
U12	Valid for left-hand drive vehicles	102A
U13	Valid for right-hand drive vehicles	33J
U13	Valid for right-hand drive vehicles	926
U13	Valid for right-hand drive vehicles	296
U13	Valid for right-hand drive vehicles	56J
U13	Valid for right-hand drive vehicles	226
U13	Valid for right-hand drive vehicles	246
U13	Valid for right-hand drive vehicles	102A
U13	Valid for right-hand drive vehicles	106A
U240	Valid for right-hand drive vehicles	26
U28	Valid for all except ECU start/stop function	26
U416	Valid for headlamp cleaning system	1116
U417	Valid for one-color ambient illumination	316
U429	Valid for three-color ambient illumination	526
U487	Valid for all except AMG	946
U57	Valid for refrigerant compressor with magnetic clutch	96
U57	Valid for model 212.2	1036
U58	Valid for model 212.2	107F
U58	Valid for model 212.0/1	1046
U58	Valid for model 212.0/1	109F
U938	Valid for ESP Basic	826
U938	Valid for ESP Basic	826

Code:	Designation:	Position:
U939	Valid for ESP Premium	836
W15/5	Left front footwell ground point	826
W15/5	Left front footwell ground point	33L
W15/5	Left front footwell ground point	93L
W15/5	Left front footwell ground point	30L
W15/5	Left front footwell ground point	57L
W15/7	Right front footwell ground point	33R
W15/7	Right front footwell ground point	93R
W15/7	Right front footwell ground point	30L
W15/7	Right front footwell ground point	57L
W19	Right front seat crossmember ground point	82L
W2	Right front ground point at lamp unit	87L
W2	Right front ground point at lamp unit	976
W9	Left front ground point (at lamp unit)	956
W9	Left front ground point (at lamp unit)	1136
X138/1	Front center console electrical connector	47H
X157/1	Center console ambience illumination electrical connector	46H
X157/1	Left front door ambience illumination electrical connector	71H
X157/4	Left front door ambience illumination electrical connector	31H
X157/4	Right front door ambience illumination electrical connector	53H
X157/5	Right front door ambience illumination electrical connector	36H
X18	Vehicle interior and harness for tail lamp electrical connector	59H
X18	Vehicle interior and harness for tail lamp electrical connector	50H
X18	Vehicle interior and harness for tail lamp electrical connector	76H
X203/4	Windshield washer system pump electrical connector	25J
X203/4	Windshield washer system pump electrical connector	106J
X25/2	Engine compartment/interior electrical connector	11H
X30/32	Left vehicle floor/interior CAN voltage distributor electrical connector	90L
X62/33	Rear axle electrical connector, right distributor	80H
X62/6	Front axle electrical connector, right distributor	88H
Y13	Fresh air/recirculated air flap switchover valve	14L
Z111	Air conditioning connector sleeve 1	9H
Z50/32Z1	Cockpit connector sleeve (fused), circuit 30	50L
Z50/32Z1	Cockpit connector sleeve (fused), circuit 30	74L
Z50/32Z2	Cockpit connector sleeve (fused), circuit 30	43L
Z50/32Z2	Cockpit connector sleeve (fused), circuit 30	67L
Z50/32Z3	Cockpit connector sleeve (fused), circuit 30	55L
Z50/32Z3	Cockpit connector sleeve (fused), circuit 30	75L

Code:	Designation:	Position:
Z50/32z4	Cockpit connector sleeve (fused), circuit 30	69L
Z50/3z1	Circuit 31 instrument panel connector sleeve	35L
Z50/3z2	Circuit 31 instrument panel connector sleeve	37L
Z50/3z2	Circuit 31 instrument panel connector sleeve	60L
Z6/56	Circuit 31 connector sleeve	95H
Z6/56	Circuit 31 connector sleeve	113H
Z6/56	Circuit 31 connector sleeve	109H
Z6/56	Circuit 31 connector sleeve	110G
Z6/97	Right lamp unit circuit 31 connector sleeve	97H
Z6/97	Right lamp unit circuit 31 connector sleeve	101H
Z61/5	Center console wiring harness circuit 31 connector sleeve	44L
Z61/5	Center console wiring harness circuit 31 connector sleeve	70L
Z61/7	Wiring harness connector sleeve for center console, terminal 58d	73L
Z6z2	Circuit 31 connector sleeve	34L
Z6z4	Circuit 31 connector sleeve	58L





Cut here