Disabling Keyless Go

To temporarily disable Keyless go operation for a specific key, press the key lock button twice in rapid succession, you will see the LED on the key blink. To enable again just push any button on the key