AR13.22-P-1202QK Remove/install poly V-belt 11.5.06


ENGINE 271.940 in MODELS 203.042 /242 /742, 209.342 /442

ENGINE 271.941 in MODELS 211.042 /242
ENGINE 271.946 in MODELS 203.046 /246 /746
ENGINE 271.948 in MODELS 203.040 /240 /740

ENGINE 271.942 in MODEL 203.043, 209.343, 203.243 /743

ENGINE 271.921 in MODEL 203.730 ENGINE 271.955 in MODELS 209.341 /441 ENGINE 271.956 in MODELS 211.041 /241

- 1 Poly-V-belt
- 2 Tensioning pulley



P13.20-2020-06

53	Removing		
1	Open engine hood	Model 203 Model 209 Model 211	AR88.40-P-1000P AR88.40-P-1000Q AR88.40-P-1000T
2	Remove wideband silencer		AR09.41-P-6825T
3	Loosen poly-V-belt (1) and remove	i Use the Torx recess below the tensioning pulley (2) for this purpose and swivel in anticlockwise direction (arrow). Take off poly V-belt (1) and decelerate tensioning pulley (2).	
4	Checking		
4	Inspect belt pulley sections and tensioning device	i Installation: Check the belt pulley sections and the tensioning device for any damage and dirt and replace if necessary.	
5	Check poly-V-belt (1)	i Installation: Replace poly-V-belt (1) if necessary.	
FAP ————	Inspect poly V-belt for wear and damage		AP13.22-P-1352Z
X	Install		
6	Fit on poly V-belt (1), tension	i Use the Torx recess below the tensioning pulley (2) for this purpose and swivel in anticlockwise direction (arrow). Fit on poly-V-belt (1) and slacken the tensioning pulley (2). i Do not use belt wax or any similar products. i Attach poly-V-belt according to the running diagram: Routing diagram of poly V-belt	AR13.22-P-3902-02QP
7	Install wide band silencer		AR09.41-P-6825T
8	Close engine hood	Model 203 Model 209 Model 211	AR88.40-P-1000P AR88.40-P-1000Q AR88.40-P-1000T

3	injury caused by contusions and burns during starting procedure or when working	Secure vehicle to prevent it from moving by itself. Wear closed and snug-fitting work clothes. Do not grasp hot or rotating parts.	AS00.00-Z-0005-01A
	near the running engine	Do not graop not or rotating parts.	
9	Carry out engine test run		