

You can use this process to put in Bi-Xenons, Clear Headlights or Depo Projectors into your car.

Lets Start on the Driver's Side

1) Remove the 8mm screw in this hole



2) Remove the 8mm bolt here



3) Jack up the car and remove the wheel

4) Remove the bottom bumper cover by taking out a few push pins and some 8mm screws

5) Remove a few push-pins and 10mm nuts, then push aside the inner fender



6) Remove the T20 Torx screw under where the bumper meets the fender



7) Pull out the bumper-fender clip. You may need a screwdriver to pry it out



12.27.2006 12:15



12.27.2006 12:15

8) Remove the 8mm bolt on top of the headlight



9) Remove the 8mm bolt on the left side of the headlight



10) Pull the bumper down a little, and remove the 8mm bolt on the right side of the headlight



11) Unplug the connector from the headlight



12) Take off the two T20 Torx screws and put the black piece on the new headlight





- 13) Place the headlight back in the hole carefully, and plug in the connector
- 14) Put the 8mm bolt back on top of the headlight



15) Put the 8mm bolt back on the left of the headlight



16) Put the 8mm and the plastic piece that goes with it back on the right side of the headlight





17) Make sure the fender clips on to the bumper





18) Put the bumper-fender clip back in, pushing towards the front of the car



19) Put the T20 Torx screw back into bumper-fender clip



20) Put the 8mm bolt back in here



21) Put the 8mm screw back in the hole



22) Put the wheel back on

Result: