



BMS Intake for 2015+ Mercedes Benz C400,C43,C45
Last updated 12/9/2018

Use subject to terms and conditions posted at <http://www.burgertuning.com/terms.html>


THIS PART IS LEGAL FOR USE ONLY IN COMPETITION RACING VEHICLES AS DEFINED UNDER CALIFORNIA LAW, AND IS NOT LEGAL FOR USE IN ANY OTHER MOTOR VEHICLE. California law defines a "racing vehicle" as "a competition vehicle not used on public highways." (Calif. Health & Safety Code 39048) This part may only be used on competition racing vehicles operated exclusively on a closed course in conjunction with a sanctioned racing event. Competition-only motor vehicles may not be driven to a racing event on a public highway and must be transported on a trailer or other carrier. USE OF THIS PART IN ANY OTHER VEHICLE MAY SUBJECT YOU TO FINES AND PENALTIES FOR VIOLATION OF FEDERAL AND/OR STATE LAW, WILL VOID YOUR WARRANTY FROM BURGER MOTORSPORTS, INC, AND CAN VOID YOUR VEHICLE'S WARRANTY. It is your responsibility to comply with all applicable federal and state laws relating to use of this part, and Burger Motorsports, INC hereby disclaims any liability resulting from the failure to use this part in compliance with all applicable federal and state laws.



Remove the engine cover using a small flat head screw driver to release the clips on the front snorkel. Pull up to remove the engine cover and place it out of the way.




After the engine cover is removed use the small flat head again to remove the air ducts from the airbox going to the side snorkels. Once removed, unclip the sensor and twist to pull the sensor out of the air box. Push those to the side for now.



Once you remove the air duct and sensor remove the bolt holding the factory intake.



Remove the nut coming off the firewall which will be used for the BMS intake heatshield.



Sandwich the BMS intake heatshield between the firewall and OEM heatshield, reinstall nut.





Install the BMS intake tubes to the turbo, if the factory oring is dry you can also lubricate it with engine oil or grease. Use the provided bolts to tighten the tubes down.

PHOTO REQUIRED

Grab the BMS filters, remove the sensors from the factory airbox and twist in to the BMS filters, using included electrical extensions to plug them back in to the factory wiring harness.



Attach filters on to tubes and adjust as needed.



If you wish to reinstall the engine cover you'll need to trim the plastic tabs as shown. Alternatively you can leave the engine cover off for a fully reversible solution. If you choose to trim the cover use a box cutter to strike it along the red lines and snap off each flap.



Reinstall snorkel, installation is complete!

