







Cut the upper oil cooling pipe with an angle grinder at the marked spot.

Connect the VÄTH transmission oil cooler with the provided fittings with the cut ends of the pipe.

Put the cooler in place as shown on the previous page and fasten it.