



SprintBooster has Arrived!



Tools Needed: Zip tie & Wire Clippers! THAT'S IT!!



2000 MB CLK 430 (W208) Engine Compartment



Work Area next to Washer Fluid Reservoir



Unplug the Wiring Harness from Throttle



Plug vehicle's wiring harness directly into SprintBooster



Plug SprintBooster into Throttle



Secure SprintBooster to throttle (loosely at first)