



P68.50-2251-09

- | | | |
|------------------|-------------|-----------------|
| 1 Bolts | 5 Ball head | 8 Connector |
| 2 Nuts | 6 Partition | 9 Adhesive tape |
| 3 Fuse | 7 Connector | 10 Partition |
| 4 Shock absorber | | |

	Remove/Install		
	Injury hazard from roll bar extending	Before working in the area of the roll bar pull rear head restraints out by hand.	AS91.00-Z-0003-01QA
1	Set up soft top bow and open soft top compartment cover		
2	Cover vehicle in rear area	To prevent scratching the paint during assembly work.	
3	Fasten partition (6) with adhesive tape (9).	Secure partition against rolling up completely with adhesive tape, because otherwise wrinkles would form at the wider end of the partition.	
4	Lift fuse (3) from shock absorber (4).		
5	Remove shock absorber (4) from ball head (5).		
6	Unhook partition (10)		
7	Unscrew bolts (1) from partition (6).		
8.1	Disconnect connector (7)	Only in combination with code 282 a ski bag (through-loading feature)	
9	Unscrew nuts (2) from partition (6).		*BA68.50-P-1001-01A
10	Detach connector (8)		
11	Remove partition (6).		
12	Install in reverse order		

Curtains/sun shades

Number	Designation	Model 209.4
BA68.50-P-1001-01A	Nut for sun shade mount	NM 8 (±0.8)