

1 Combination filter

2 Nut 3 Combinati

Combination filter housing

Clamp

4

X	Remove/install	
1	Open engine hood	AR88.40-P-1000TX
2	Unscrew nut (2)	
3	Unclip combination filter housing (3) from clips (4) and remove	
4	Remove combination filter (1) from the combination filter housing (3)	
5	Install in the reverse order	

P83.00-2159-07