

Shown with code (540) Electric sun shade for rear window

- Spreading clip 1
- Bolt (with code (540) Electric sun 2 shade for rear window)
- Rear shelf paneling З
- Insulation mat 4

H4/17 Bass module speaker

XX	Remove/Install		
1	Completely move both front seats toward front	i To protect the front seat backrests.	
2	Remove rear seat backrest		AR91.12-P-1620TX
3	Remove left and right rear head restraint		AR91.16-P-1770TX
4	Remove left and right paneling from C-pillar		AR68.30-P-4490TX
5	Remove expanding clips (1)	i Installation: Replace damaged expanding clips (1) with new ones.	
6.1	Unscrew bolts (2)	On vehicles with code (540) Electric sun shade for rear window I Access via luggage compartment.	
7	Lift up rear shelf panel (3) and disconnect electrical connectors from bass module speaker (H4/17)		
8	Lift up rear shelf panel (3) and rotate bass module speaker (H4/17) counterclockwise and take off of rear shelf toward front	(4).	
9	Install in the reverse order		

7.9.04