



P82.62-2817-09

Shown with code (540) Electric sun shade for rear window

1 Spreading clip  
2 Bolt (with code (540) Electric sun shade for rear window)

3 Rear shelf paneling  
4 Insulation mat

H4/17 Bass module speaker

	Remove/Install		
1	Completely move both front seats toward front	To protect the front seat backrests.	
2	Remove rear seat backrest		<a href="#">AR91.12-P-1620TX</a>
3	Remove left and right rear head restraint		<a href="#">AR91.16-P-1770TX</a>
4	Remove left and right paneling from C-pillar		<a href="#">AR68.30-P-4490TX</a>
5	Remove expanding clips (1)	<b>Installation:</b> Replace damaged expanding clips (1) with new ones.	
6.1	Unscrew bolts (2)	On vehicles with code (540) Electric sun shade for rear window Access via luggage compartment.	
7	Lift up rear shelf panel (3) and disconnect electrical connectors from bass module speaker (H4/17)		
8	Lift up rear shelf panel (3) and rotate bass module speaker (H4/17) counterclockwise and take off of rear shelf toward front	Pay attention to sound deadening mat (4).	
9	Install in the reverse order		