



P68.20-3249-07

Shown with code (889) Keyless Go

1 Ashtray housing
2 Selector lever

3 Center console cover
4 Electrical connector

5 Electrical connector (with code (889) Keyless go)

☒ ☒	Remove/install		
1	Move selector lever (2) to rear-most position.		
2	Open ashtray housing (1)		
3	Press center console cover (3) toward rear and hold down. Unclip center console cover (3) upward in front area (arrow) Then raise center console cover (3) at front and slide toward front until center console cover (3) is unhooked in rear area.		
4	Pull ashtray housing (1) out of center console until electrical connectors (4, 5) are accessible	Electrical connector (5) only on vehicles with code (889) Keyless Go	
5	Disconnect electrical connector (4)		
6.1	Disconnect electrical connector (5)	On vehicles with code (889) Keyless Go	
7	Remove ashtray housing (1)		
8	Install in the reverse order		