



P68.10-3803-07

Shown on model 204.0

- | | | | | | |
|---|-------------------|---|-----------------------------|--------|--|
| 1 | Cover | 4 | Bolts | B10/36 | Right front footwell air outlet temperature sensor |
| 2 | Door sill molding | 5 | Bottom of A-pillar paneling | E17/15 | Right front footwell lamp |
| 3 | Edge guard | 6 | Catch hook | | |

☒ ☒	Remove/install		
1	Adjust right front seat toward rear to end position		
2	Remove door sill molding (2)	Model 204, 207	
3	Loosen edge guard (3) in area of bottom A-pillar paneling (5).	Model 204, 207	
4	Remove A-pillar paneling at bottom (5)	Model 204, 207	
5	Fold floor covering to passenger side	Model 212, 218	
6	Unscrew bolts (4) and lower cover (1)	i Installation: Guide catch hook (6) into corresponding lug on AC housing.	
7	Disconnect electrical connector from air outlet temperature sensor on right front footwell vent (B10/36) and right front footwell lamp (E17/15)		
8	Remove cover (1) out of the footwell		
9	Install in the reverse order		