

- 1 Move soft top to assembly position.
- 2 Check manufacture date (2) on production label (1).



P77.31-2212-04

i On soft top canvas with short elastic band with manufacture date (2) before 22.02.2007 use attachment point on rear window bracket.

i On soft top canvas with long elastic band with manufacture date (2) as of 22.02.2007 use modified attachment point on rear window lever.