

Step1: My '96 E320 glove compartment



Step2: Inside look



Remove these 6 screws only (2) facing you (2) below covered by plastic caps and (2) on both sides of the light screwing upwards... DON'T need to remove screws with rubber caps facing you. They are there as stops when you close your glove compartment. Pull unit hard towards you & remove it

Step3: Disconnect light



Step4: Disengage cover plate by moving a plastic clip up



Step5: Now you can remove the cover plate



Step6: Now you can remove the old cabin filters



Step7: Put in new cabin filters



Step8: Reverse process to (a) connect light wire (b) reinstall all 6 screws