

P82.10-3356-07

Shown on model 211.2

1 Electrical connector





2 Nut

3 Clamping piece

5 Angle bracket

E3/1 Left rear-end door taillamp

E4/1 Right rear-end door taillamp

 	Remove/install		
1.1	Remove all paneling from rear-end door	Model 211.2	AR72.20-P-3520T
1.2	Remove existing paneling from rear-end door until the left rear-end door taillamp (E3/1) or right rear-end door taillamp (E4/1) is accessible	Model 211.6	
		 Whether paneling exists or what paneling versions are used depends on the vehicle equipment.	
2	Disconnect electrical connector (1)		
3	Unscrew nut (2) and remove clamping piece (3)		
4	Remove left rear-end door taillamp (E3/1) or right rear-end door taillamp (E4/1) from rear-end door	 Installation: Check correct seating of retaining brackets (5) on rear-end door.	
5	Install in the reverse order		