



P68.10-2790-09

Shown on removed glove compartment

1 *Glove compartment lid*  
2 *Pin*

3 *Hinge*  
4 *Shock absorber*

| ☒ ☒ | Remove/install  |  |                 |
|-----|---|--|-----------------|
| 1   | Remove cover below right instrument panel                             |  | AR68.10-P-1520T |
| 2   | Press bolt (2) out of hinges (3) with suitable pliers                 |  |                 |
| 3   | Remove glove compartment cover (1) out of hinges (3)                  |  |                 |
| 4   | Unhook damper (4) and remove glove compartment cover (1)              |  |                 |
| 5   | Install in the reverse order  |  |                 |
| 6   | Check adjustment of glove compartment cover (1), adjust if necessary. |  | AR68.10-P-1300T |