



P91.12-2568-07

Shown on left rear seat backrest

1 Backrest frame
2 Catch

3 Bolts

4 Plug-in wiring plug connection

	Remove/Install		
1	Remove rear seat backrest upholstery	Applies to left rear seat backrest. Applies to right rear seat backrest	AR91.12-P-1030TC AR91.12-P-1030TD
2	Unscrew screws (3)		*BA91.12-P-1015-02A
3	Disconnect electrical connector (4) from locking system (2)		
4	Remove locking system (2) from backrest frame (1)		
5	Install in the reverse order		

 Rear seat backrest

Number	Designation	Model 211.2
BA91.12-P-1015-02A	Screw, rear seat backrest lock to backrest frame	NM 23