

P72.12-2212-09

Shown on model 211.0 with code (889)

Keyless go


- 1 Outer door handle
2 Door handle cover
3 Rubber seal
4 Bolt

- 5 Electrical connector
(with code (889) Keyless go)
6 Connection
(with code (889) Keyless go)

- 7 Screwdriver
8 Gaskets
9 Bearing bracket

Modification notes

22.4.03	Commercially available tools replaced	Step 2	
---------	---------------------------------------	--------	--

	Remove/Install		
1	Remove rubber seal (3) in area of access cover (arrow)	i Installation: Ensure that rubber seal (3) is seated correctly.	
2	Unscrew bolt (4) only until door handle cover (2) is loose	i Access to bolt (4) via access cover (arrow). 	*WH58.30-Z-1059-06A
3	Pull outside of door handle (1) and remove door handle cover (2)		
4	Remove outer door handle (1) backwards out of the rear door	i On vehicles with code (889) Keyless go, pull outer door handle (1) out of rear door until electrical connector (5) is accessible. i Installation: Ensure that the seals (8) are seated correctly.	
5.1	Disconnect electrical connector (5)	On vehicles with code (889) Keyless go i Hold connection (6) of electrical connector (5) with screwdriver (7) This prevents the connection (6) from being unhooked from the bearing bracket (9).	
6	Remove outer door handle (1)		
7	Install in the reverse order		

Commercially available tools

Number	Designation
WH58.30-Z-1059-06A	TORX-screwdriver, length 250 mm, T20