

Kabel Daviko W212/A207 Halogen to Xenon Wiring Harness Part # 212/207-741

Route the harness from the front SAM module box to new left and right Xenon headlights.

Plug the gray connector into the new Xenon headlights and the original Halogen connector onto the black mating connector. Connect both ground cables to best chassis ground.

On the left, please lay the plug for the front level sensor to the left front and connect to sensor.

Run the 4 pin (pink) of SAM connector 22I harness to distribution block under rear seat bench.

Modify the existing SAM module plugs 21M & 20M as follows (22I -yellow plug already wired)

SAM front plug 21M

white/yellow	Pin 1
yellow	Pin 2
brown/white	Pin 8
red/green	Pin 9
green/white	Pin 18

SAM front plug 20M

white/yellow	Pin 2
yellow	Pin 3
Note: It doesn't matter which connector the yellow/white and yellow cable pairs are connected . Both are CAN-G	

Socket under rear bench seat

brown	Pin 1
green/black	Pin 2
red/green	Pin 3
free	Pin 4

