

Model 213 with transmission 725

- 1 Cover
- 2 Stop buffer
- 3 Bolt



P68.20-4996-12

☒ ☒	Remove/install		
1	Open armrest cover		
2	Remove stop buffer (2)		
3	Remove bolts (3)		
4	Take off cover (1)		
5	Install in reverse order		