

How to install running boards on a Mercedes 2017 GLE350.

1. Tools required

- a. 10mm driver
- b. Flat bladed screwdriver



- c. 8 nuts, 4 screws and 2 blank panels came with running boards. No idea what the screws were for.

2. Remove the 3 fasteners from the front of the running board and 2 from the rear. Use the flat blade screwdriver to pull out the center pin. Then pry out the entire fastener.



3. Remove the 6 bolts from bottom of the board.



4. You will now be able to remove the running board. There are clips along the top edge of the running board and they will release with a slight amount of pressure.
5. Now remove the support panel by removing the 6 nuts.





6. Install the new support bracket with 10 nuts



7. A word of caution. Be sure front edge of support bracket goes ABOVE the existing mud shield.



8. Install running board. Caution: Be sure that the running board goes BEHIND the existing mud shield.



9. The running board is held on by clips at the top of the support bracket and several clips underneath the board. Insure all clips are secure.
10. Reinstall the push in fasteners that were previously removed from the front and back edge of the running board.

11. Install spacer that goes at the front edge of the rear door and you are done.



12. Entire operation is easily completed in 2 hours.

