

Grab Handle replaced with Sunglass Holder

Note: This holder will not hold bulky sunglasses, I have Serengeti with metal frame and they fit OK



So here is the step by step of what I did.

Here's what you will need

Parts List

B200 Sunglass Holder: A169 819 0041 \$28.40 CAD



Clips: NAPA Auto Parts 665-1036, these snap in very tight. I removed two of the tabs since they weren't clipping to anything.

Head size 16mm or 5/8"

Stem length 7mm or 5/16"

Stem size 10mm or 13/32"

<https://www.napaonline.com/Catalog/Result.aspx?Ntt=665-1036&Ntk=Keyword&Nty=1&Dn=0&D=665-1036&Dk=1&Dp=3&N=0>



1/4" X 1/2" length screws



Remove the grab handle

First remove the retainer clip, slip the tool in the small opening and pull towards you at a 45 degree angle, see pic of what the clip looks.





Once the retainer clip removed, use the same tool to pry apart, insert in small hole pry and pull at the same time, once one side released insert tool in the middle hole to release the other side. see picture below of the clip set up





Once the handle removed it should look like this.



Sunglass Holder



Unfortunately the clips are not the same (don't understand this one, you would think MB would make this standard!?!?!?!?)

Use a dremmel tool to grind away the clips

Before



After



I used a drill bit to make the hole bigger in the bottom of the middle opening where the screw will go in, not much.



Insert Clip





You will need to line these up, approx. width is 5" 5/8" centre to centre.





This is the Dremmel bit I used



This is the paint I might use



If you have any questions don't hesitate to PM me