AR62.30-P-2500GYRemove/install dome strut10.5.06

MODEL 164.8



P62.30-2913-09

Shown on model 164.8 with engine 629

1 Clamps 2 Air inlet for air conditioning 3 Bolt 4 Nuts 5 Bolts 6 Nuts 7 Bracket, left ADS sensor 8 Dome strut

XX	Remove/install	
1	Open engine hood	AR88.40-P-1000GZ

2	Loosen clamps (1), remove air inlet for air conditioning (2) upwards	i Installation : The lug at the bottom of the air inlet for air conditioning (2) must engage in the corresponding guide.	
3	Unscrew nuts (6), place bracket of left ADS sensor (7) to one side	i Do not separate the left ADS sensor (7) electrically.	
4	Remove bolt (3)		
5	Unscrew nuts (4)	Nm	<u>BA62.30-P-1005-</u> 02D
6	Remove bolts (5) to the rear		
7	Lift dome strut (8) on the left side slightly and remove to the left (arrow)	i Installation: Check the seat of the rubber seal through which the dome strut (8) runs.	
8	Install in the reverse order		

Nm Front end assembly with front reinforcement

Number	Designation		Model 164.8	
BA62.30-P-1005-02D	Nut, for dome strut bolted connection to bracket		Nm	50