



P62.30-2913-09

Shown on model 164.8 with engine 629

- |   |                            |   |                         |
|---|----------------------------|---|-------------------------|
| 1 | Clips                      | 5 | Bolts                   |
| 2 | Air conditioning air inlet | 6 | Nuts                    |
| 3 | Screw                      | 7 | Left ADS sensor bracket |
| 4 | Nuts                       | 8 | Strut tower brace       |

## Modification notes

25.7.08	"Wax bolted connections" added	Step 6	*BR00.45-Z-1018-05A
---------	--------------------------------	--------	---------------------

	Remove/install		
1	Open engine hood		AR88.40-P-1000GZ
2	Loosen clamps (1), remove air conditioning air inlet (2) upward	<b>i</b> <b>Installation:</b> Bottom lug on air conditioning air inlet (2) should reach into corresponding guide.	
3	Unscrew nuts (6), place left ADS sensor bracket (7) to one side	<b>i</b> Do not disconnect left ADS sensor (7) electrically.	
4	Remove bolt (3)		
5	Unscrew nuts (4)	<b>Nm</b>	*BA62.30-P-1005-02D
6	Remove bolts (5) toward rear	<b>i</b> <b>Installation:</b> Wax bolted connections.	*BR00.45-Z-1018-05A
7	Slightly raise strut tower brace (8) on left side and remove left toward (arrow)	<b>i</b> <b>Installation:</b> Check whether rubber seal, through which the strut tower brace (8) runs, is correctly seated.	
8	Install in the reverse order		

**Nm** Front end assembly with front reinforcement

Number	Designation	Model 164.8
BA62.30-P-1005-02D	Nut, for dome strut bolted connection to bracket	Nm 50

## Repair materials

Number	Designation	Order number
--------	-------------	--------------

