


Smartkey Starter™ Installation Instructions 2012+ Mercedes Benz ML Class 2013+ Mercedes Benz GL Class

Tools and parts you will need

- T-20 driver
- Drill
- 3/4" drill bit or unibit


The Smartkey Starter™ is designed as a direct plug in interface to the rear of the Mercedes Benz key cylinder. Please read this manual in it's entirety prior to installation as there is a specific order of operation that needs to be followed.



Installation Diagram

Installation

1. Remove (3) T-20 screws from the driver's under dash panel.
2. Lower dash panel down and move air vent out of the clips that hold it in place.
3. Reach up to the rear of the EIS. There are two retaining clips on the top and bottom of the EIS.
4. Grasp the wiring harness while squeezing the retaining clips together to remove the EIS.
5. Pull the EIS with harness attached out of the dash to access the wiring.
6. Unplug both plugs (blue and green) from the EIS.
7. Remove the blue housing from the harness and install it on to the supplied Smartkey Starter® T-harness.
8. Install the supplied white housing on to the empty plug where the blue housing originally was.
9. Plug the T-harness into the factory wiring and the EIS.
10. Once ALL connections are secured, turn on the valet switch and verify the LEDs visible inside the Smartkey Starter™ are flashing.
11. Start the vehicle with the key or with the push button to verify your work. If the vehicle starts and runs, you've made all the connections correctly.
12. Shut the vehicle off.
13. Push the panic button once on the remote to test the Smartkey Starter™.
14. Once you are satisfied with its operation, shut down the Smartkey Starter™ by pushing the panic button once.
15. Locate a place to secure the Smartkey Starter™ module in the dash cavity away from any heat sources.
16. Secure the module in its final location.
17. Locate a place for the valet override switch. Recommended location is the driver's underdash panel.
18. Drill a $\frac{3}{4}$ " hole in the desired location.
19. Route the wires for the valet switch through hole made in step 18.
20. Plug in the valet switch to the Smartkey Starter™ valet switch leads. Make sure the spade connectors are fully installed on the switch.
21. Line up the vent to the under dash panel in the clips that hold it into place.
22. Reinstall the under dash panel making sure the vent is lined up to the duct in the dash.
23. Reinstall (3) T-20 screws to hold the panel in place



Remove (3) T-20



Lower panel and move vent



EIS removed



T-harness installed