- Armrest cover
- 2 Bolts
- 3 Portable CTEL stowage tray
- Electrical connector
- 4 5 6 Plug connections
- Clamp
- Guide lug



P82.70-5454-06

XX	Remove/install		
1	Unlock armrest cover (1) and set upright		
2	Remove bolts (2)		
3	Unlock stowage tray and set upright		
4	Lift portable CTEL stowage tray (3) (arrow A) and pull forward	<b>i Installation:</b> Pay attention to installation position of guide tab (7).	
5	Turn over portable CTEL stowage tray (3)		
6	Disconnect electrical connector (4)		
7	Unclip connectors (5)		
8	Remove clamp (6)		
9	Install in the reverse order		