



P54.10-2555-09

Shown on model 251.1

- 1 Impact damper
- 2 Intermediate bottom
- 3 Nuts
- 4 Clips
- 5 Nuts
- 6 Plug on negative terminal
- 7 Plug on positive terminal
- 8 Bolt
- 9 Retaining clamp
- 10 Anchor fitting
- G1/7 Additional battery

Modification notes

26.7.06	Disconnect/connect battery ground line and carry out basic programming removed	Steps 1 and 11	
---------	--	----------------	--

Remove/install		
1	Remove front floor covering	i Right side of vehicle AR68.20-P-2070RT
2	Remove impact absorber (1)	
3	Unscrew nuts (3, 5) and remove clips (4)	i Installation: Do not mix up nuts (3) and nuts (5). i Installation: Pay attention to correct seat of clips (4). Cordless drill/driver *WH58.30-Z-1007-20A
4	Remove intermediate bottom (2)	
5	Detach plug on negative terminal (6) of additional battery (G1/7)	
6	Detach plug on positive terminal (7) of additional battery (G1/7)	
7	Undo bolt (8), open retaining clamp (9)	i Installation: Ensure that the anchorage fitting (10) engages into the retaining panel. *BA54.10-P-1014-01C
8	Remove additional battery (G1/7)	
9	Install in the reverse order	

Nm Battery

Number	Designation	Model 251

BA54.10-P-1014-01C	Nut of additional battery retaining clamp	M6	Nm	5
--------------------	---	----	----	---

Commercially available tools

Number	Designation
WH58.30-Z-1007-20A	Cordless drill/driver