

# ... CHASSIS QUICK REFERENCE Incl. all AMG, Black Series

**FINALLY - ON GOING / PRECISE ADJUSTMENT Resolve Steering Pull, Premature Edge Tire Wear**

## FRONT (CAMBER & CASTER) - All Incl. Airmatic, ABC, 4Matic, AMG

'09-'18	W212 / S212, W218 E63 AMG, CLS63 AMG Also Adj. Strut Top Mounts - If Coil Spring Suspension	( Popular A, B, CLA, GLA see below * ) Stage 2 (Street/Race) Stage 3 (Full Race)	# 502916 K # 503116 K # 502916-2 L # 502916-3 L
'14-'18	W205 / S205 C180, C200, C220, C250, C300 C400, C450, C43, S63 AMG (4 MATIC) C63 / S, S63 / S65 AMG		# 503216 K # 503416 K # 503316 K
'13-'18	C213 / C238, C217 / A217, W222, X253		# 502816 L
'02-'18	W204, X204, C207 / A207 Also Adj. Strut Top Mounts - for C209 'Black' Series (only) Also Adj. Strut Top Mounts - If Coil Spring Suspension W204/X204, C207/A207 (Incl. 'Black' Series)	Incl. 'Black' Series W204, C209 Stage 2 (Street/Race) Stage 3 (Full Race) Stage 2 (Street/Race) Stage 3 (Full Race)	# 502616 K # 502616-2 L # 502616-3 L # 503016-2 L # 503016-3 L
'99-'06	W215, W220		# 502516 K
'95-'09	"4Matic" - W210, W211 / S211, W220		# 502416 K
'00-'13	W216, W221		# 502316 K
'00-'18	R171 / 172, W203, C209 / A209, W211 / 219, R230 / 231	Black Series See above W204	# 502216 K
'95-'02	W210		# 502116 J
'83-'02	R170, W202, C208 / A208	Incl. Chrysler Crossfire (300C, Charger, #502716 K)	# 502016 J
'91-'99	W140	Has adjustment K-MAC doubles adj. range	# 501916 K
'82-'01	W124 / C124, R129, W201	Has adjustment K-MAC doubles adj. range Also (124,129) Adjustable Strut Top Mounts available (#501716-2 L, #501716-3 L)	# 501716 J
'77-'91	W123, W126	Camber only	# 501616 H

## REAR (CAMBER & Extra TOE) - All Incl. Airmatic, ABC, 4matic, AMG See also Performance Rear Link Bushings (page 14)

'01-'18	W211/S211, W216, W219, W221, W222, R230, R231		# 502526 K
'00-'18	W204, X204, W205/S205, C207/A207, W212/S212, C213/C238, W215, C217, W218, W220, X253		# 502226 K
'01-'18	C209 / A209 ('01-5/04), R171, R172	(33mm Lower Arm/Inner bush)	# 502026 H
'04-'09	C209 / A209 (6/04-'09)	(51mm " " " " )	# 501926 J
'07-'09	C209 ('Black' Series)	(33mm " " " " )	# 501526 H
'91-'98	W140	(51mm " " " " )	# 501626 J
'82-'03	W124 / C124, R129, R170, W201, W202, *C208, W 210	Incl. Chrysler Crossfire (300C, Charger #502726 K) *A208 Convertible	# 502026 H # 501426 i
4/04-'07	W203	(51mm Lower Arm/Inner bush)	# 501926 J
'00-3/04	W203	(33mm " " " " )	# 502026 H
'68-'91	R107, W114, W115, W116, W123, W126		# 501826 i

## SUV, SPRINTER, VITO, A/B/CLA/GLA Class FRONT - Camber & Caster REAR - Camber & "X" Toe

W164 / X164, W166/X166, W251, C292	Front also replaces / strengthens the (costly) Lower / Inner Rear bushes!	FRONT # 504016 M # 503916 G	REAR # 504026 K # 503926 J	Has Rear Adj. K-MAC doubles adjustment range.
Sprinter W906 ('06-'18)	Full Camber & Caster	# 505416 K		
W903 ('95-'06)	Capability plus steering	# 505316 K		
	Camber Only ('06-'18) See Maxi Camb Page 10	# 505016 D		
Vito W639 ('11-'18)	Full Camber & Caster	# 505216 K	# 505026 K	W638, W639
W639 ('04-'11)	Capability plus steering	# 505116 K	# 505226 K	Long W/Base ('04-'18)
W638 ('96-'03), W639 ('04-'18)	Camber only	# 120216 D		
A, B, CLA, GLA, AMG ('98-'18)	Front Camber Only	# 120216 D		
W168, W169, W176, W245, C117, X156	Strut Top Mounts ('13-'17) Stage 2 (Street/Race) (Precise Camber & Caster) Stage 3 (Full Race)	# 506116-2 L # 506116-3 L	# 506126 K ('13-'18)	

\*