

## **NO-DRILL** Rear Spoiler **Installation Instructions**

The part you have chosen is a **NO-DRILL** application, which means there are **NO TOOLS NEEDED** for a successful installation.

**Always test fit and inspect part before any prepping, paint work or installation begins.**



### **Step 1. Surface Cleaning**

Clean surface area that is covered by spoiler thoroughly with Isopropyl Alcohol.



### **Step 2. Test Fitting**

Simply test fit the spoiler for proper placement. Mark your position with masking tape.



### **Step 3. Preparation**

Peel back the corner of the red liner on the 3M tape and remove all pieces, avoid touching the exposed tape. We recommend using an adhesive silicone in strategic locations in conjunction with the 3M tape for best results.



### **Step 4. Installation**

Gently press spoiler into place on the deck lid, hatch or rear glass. Once satisfied with placement, firmly press down on spoiler to ensure adhesion along entire vehicle surface. Continue to apply pressure until satisfied.

