

Always install the rear locks on '95-'02 models in fully open position—push with your finger as shown to make sure the lock is positively latched open.

