



P68.10-4517-09

- | | | |
|----------------------------|------------------------|---------------------------|
| 1 Bolts | 4 Electrical connector | E17/16 Left footwell lamp |
| 2 Cover | 5 Electrical connector | X11/4 Data link connector |
| 3 Engine hood cable handle | 6 CAN hub | |

☒ ☒	Remove/install		
1	Unscrew bolts (1) and unclip cover (2) downward	ⓘ Lower cover (2) downward only until engine hood cable handle (3), electrical connectors (4, 5), CAN hub (6) and data link connector (X11/4) are accessible.	
2	Unhook engine hood handle (3)		
3	Disconnect electrical connector (4)		
4	Release data link connector (X11/4) and take out of cover (2)		
5	Disconnect electrical connector (5) from left footwell lamp (E17/16)		
6	Unclip CAN hub (6)		
7	Remove cover (2) out of the footwell		
8	Install in the reverse order		