



P80.30-2162-07

Shown on model 230.4 without code
(P99) Special model "AMG Black Series"

1 Panel
2 Rubber seal
3 Screw
4 Lock guide cylinder

5 Electrical connector
6 Door handle

A26/1 Left front IR receiver
A26/2 Right front IR receiver

	Remove/install		
1	Remove covering (1) from left and right front door		
2	Remove rubber seal (2) until bolt (3) is accessible		
3	Unscrew bolt (3)	Nm	*BA72.10-P-1005-01AB
4	Pull lock cylinder guide (4) with left front IR receiver unit (A26/1) or right front IR receiver unit (A26/2) out of front door until electrical connector (5) is accessible		
5	Disconnect electrical connector (5) and remove left front IR receiver unit (A26/1) or right front IR receiver unit (A26/2)		
6	Install in the reverse order		

Front door

Number	Designation	Model 230
BA72.10-P-1005-01AB	Bolt, guide of lock cylinder to front door	Nm 3