



Mercedes-Benz W211 AMG Carbon Fiber Rear Diffuser IMPORTANT INSTALLATION NOTES

1. Remove stock black plastic piece on bumper
2. Clean off stick residue with adhesive remover.
3. Clean surface with rubbing alcohol thoroughly! Then wipe dry.
4. Clean surface again with rubbing alcohol, then wipe dry. (Very important step to keep tape sticking forever!)
5. Line up diffuser and mark gold screw area with a pen or marker on bumper.
6. Drill holes once it is lined up, you may need to move the hole, or make it bigger or slide it to the side once it is in.
7. Make sure it is lined up on both sides. I.e. make sure the screw holes are posited right when holding diffuser against the car.
8. Peel off sticky tape edges with a razor blade.
9. Apply lots of pressure to make sure tape is holding.
10. Use the washers and nuts and long extension ratchet or screw driver to tighten the side screws. You need the extension because access is hard with behind the exhaust tips.
11. DO NOT OVERTIGHTEN. Side screws are only glued on by epoxy and are not mean to be VERY tight.
12. INSTALATION COMPLETE.