


Long wedge

Illustrated on model 212

- Remove catch hooks (1) with Ilong wedge through shaft of Audio/COMAND display and remove cover (2) upward from instrument panel.
- 2 Remove cover (2) from instrument panel.
- Disconnect electrical connector (3) from PARKTRONIC instrument panel warning indicator.

 Only on vehicles with code (220) PARKTRONIC or with code (230) Exclusive parking assist



- 4 Disconnect electrical connector (4) from sun sensor.
- 5 Install in the reverse order.