




Code	Designation	Coordinates
A0	Color code key	48L
A2	Radio	4A 9A 14A 15L
A2/6	CD changer	9L 25L
A2/10	TV tuner	32L
A2/56	Radio control panel and navigation unit	14L
A34/4	Telephone interface	20A
A35/1	Hands-free system control unit	32A
A35/11	Voice control system control unit	31A 44A
A40/3	COMAND operating, display and control unit	15L 19L
A90/1	TV combination tuner (analog/digital)	32L
N41/1	Navigation processor	26A
N93/1	Audio gateway control unit	4L 14A
N112	Telecommunications control unit	19A 20A
N123/1	Universal Portable CTEL Interface (UPCI [UHI]) control unit	36A 41A
U2	Valid for all (except  )	11A
U52	Valid for 	16B
U88	Valid for radio control panel	11H
U193	Valid for TV and Video	29G
U196	Valid for VCS [SBS]	29A 38A
U236	Valid for COMAND operating unit, ECE version	12J
U237	Valid for COMAND operating unit,  version	17H
U534	Valid for Radio	12B
U587	Valid for radio with APS	12J
U594	Valid for fixed installation telephone	16A
U689	Valid for telephone basic equipment	16A
U761	Valid for MOST bus (minimum equipment)	1A 6A
U762	Valid for MOST bus (maximum equipment)	11A
U788	Valid for hands-free system	29A
U801	Valid for UHI (Universal Portable CTEL Interface)	34A 39A
U814	Not valid for radio	12B
X30/8	Wake-up signal connector	26F
X39/50	Fiber optic cable connector (MOST)	15D 17H 22D 25H 27D 33H
Z35/10	MOST wake-up signal connector sleeve	39D
Z35/11	Optical conductor connector sleeve	15D 18G 22D 25G 28D 34G