




Mercedes-Benz



Operation Guide

Please familiarize yourself with these operating instructions and the voice recognition system before attempting to operate it while driving.

We continuously strive to improve the voice recognition system and we ask for your understanding that we reserve the right to make changes in design and equipment. Therefore, information, illustrations and descriptions in this operating manual might differ from your vehicle.

If there are any equipment details that are not shown or described in these operating instructions, or if you have any questions regarding the descriptions or the operation of the voice recognition system, your authorized Mercedes-Benz Center will be happy to assist you.

Please read this manual carefully before putting it aside. Then return it to your vehicle where it will be handy for your reference.

We extend our best wishes for many miles of safe, pleasurable driving.

DaimlerChrysler Aktiengesellschaft

Introduction.....	3	Audio operation.....	20
Activation/deactivation of Voice Recognition using: Operating lever.....	5	Radio.....	21
Multifunction steering wheel with operating lever...	7	Radio commands.....	22
Telephone operation.....	8	“Help radio”	22
Dialog description	9	“Seek” / “Next station”	22
Telephone commands	11	Select Frequency (FM)	22
“Help” / “Help phone”	11	“FM”	
“Enter unlock code”	11	“AM”	
“Dial Number”	12	“Weatherband”	22
“Confirm”	13	“Store station” (station list).....	23
“Correction”	13	“Select station” (station list).....	23
“Delete”	14	“Station list”	24
“Store Name”	14	“Delete station” (station list).....	24
“Dial Name” (telephone book).....	16	“Delete station list”	25
“Delete Name” (telephone book)	16	CD-Changer or Single CD	26
“Delete phone book”	17	CD-Commands.....	26
“Phone book”	18	“Help CD” / “Help CD-Changer” / “Help Single CD”	26
“Redial”	18	“CD 1” to “CD 6”	26
Managing an automated answering system/ voice mail operation.....	19	“Next CD”	26
		“Track 1” to “Track 19”	27
		“Next Track”	27

Table of Contents

Cassette player.....	27
Cassette player commands	28
“Help Tape”	28
“Next track”	28
“Seek”	28
“Other side”	28
“Fast forward” or “Rewind”	28
Navigation.....	28
Troubleshooting.....	29
List of commands.....	31
Index.....	37

Introduction

Warning!

Please devote your attention first and foremost to the traffic situation you are in. While the system permits hands-free phone operation, attention to traffic may be diverted not only by physical operation of a phone, but also by the distraction of a phone conversation while driving. As such, for safety reasons, we encourage the driver to stop the vehicle in a safe place before answering or placing a phone call.

Please keep in mind that at 30 m.p.h. your vehicle is travelling at 44 feet per second.

Important!

Please do not use the voice recognition system in an emergency, as the tone of your voice may change in a stressful situation. Due to circumstances this could cause a delay in completing your phone call in a timely manner.

You have the capability of operating your vehicle's cellular phone, radio, single CD-player, CD-changer and the cassette player using verbal commands using the voice recognition system. The navigation system can be turned on using a verbal command.

In conjunction with the cellular telephone's hands-free feature, you can operate your telephone without picking up the receiver handset.

The vehicle's radio must be switched on in order to operate the voice recognition system. Subsequently activate the voice recognition system, page 5, 7. Use the voice recognition system to enter the unlock code for your cellular phone or to select an audio component. Use a verbal command to select the corresponding component, e.g. "Radio". If you would rather listen to CD of the CD-Changer, use the verbal command "CD-Changer" to select the component, activate the voice recognition system again and then use the command "CD 5" to select the CD number 5.

The voice recognition system recognizes approx. 100 different commands, irrespective of the speaker. The voice recognition system asks "Please repeat?" for a new command if an unavailable or incorrect command is used.

Introduction

In order to provide for a safe and comfortable dialog, the voice recognition system acknowledges important commands.

The commands and digit sequences can be spoken without pausing between the individual words.

The voice recognition system contains a noise reduction function to suppress background noise to enhance performance while driving.



The voice recognition system also contains an extensive help function.

Help can be accessed at any time by saying the command "Help".

You also have the possibility to directly select the help function for a particular component.

Following Help commands are possible:



- "Help"
- "Help Phone"
- "Help Radio"
- "Help CD"
- "Help Tape"

If during voice output of the available commands, the operating lever is pulled briefly to position  or the  button is pressed, the last command read out is performed, page 6, 7.

Activation/deactivation using operating lever




The operating lever for the voice recognition system is located on the right side of the steering column.

- 1 Activate voice recognition system/ accept incoming telephone call (position 1 )
- 2 Deactivate voice recognition system (position 2 )

Turn the electronic key in the steering lock to position 1 or 2. The vehicle radio must be switched on and the system is ready to use.

Activate voice recognition system

Briefly pull operating lever to position 1  .

Activation is confirmed by an audible tone (beep). You may begin using the voice recognition system now.

Deactivate voice recognition system

Briefly push operating lever to position 2  or state the command "Cancel".


If the voice recognition system is deactivated during a dialog, then the complete procedure is stopped and voice recognition is cancelled.

Introduction

Set volume level

When the voice recognition system is activated you can set the volume of the voice output using the volume control on the vehicle's radio.


Receive incoming phone calls

Briefly pull operating lever to position 1  .


Select phone book entry during voice output

Briefly pull operating lever to position 1  , see page 20.

Dial telephone number

Briefly pull operating lever to position 1  .

End telephone call

Briefly push operating lever to position 2  .


Select a station during voice output

Briefly pull operating lever to position 1  , see page 26.

Stop winding action of cassette player


Briefly push operating lever to position 2  , see page 30.


Activation/deactivation of voice recognition using multifunction steering wheel with operating lever





CL-Class illustrated, other models slightly different



Turn the electronic key in the steering lock to position 1 or 2. The vehicle's radio must be switched on and the system is ready to use.


1 Activate voice recognition system – Briefly pull operating lever to position 1 . Activation is confirmed by an audible signal tone. You may begin using the voice recognition system now.

2 Deactivate voice recognition – Briefly push operating lever to position 2 , or state the command “Cancel”. If the voice recognition system is deactivated during a dialog, then the complete procedure is stopped and voice recognition is cancelled.

3 Increase volume – Press  button.

4 Decrease volume – Press  button.

When the voice recognition system is activated you can set the volume of the voice output using the volume control on either the vehicle's radio or by pressing the  or  buttons .

5 To receive an incoming telephone call – Press  button.



During voice output – Press  button, the telephone book or station list entry is selected, page 20.

To dial a phone number – Press  button

6 To end a telephone call – Press  button.

Telephone

Messages in the Multifunction display

On vehicles equipped with a multifunction steering wheel, press button  or  repeatedly until the telephone symbol appears in the multifunction display. The spoken digits will be displayed there.

Telephone operation

You have the capability of operating your vehicle's cellular phone using verbal commands using the voice recognition system (hands-free operation).

Additionally, you have the capability of creating a phone book. Frequently used phone numbers can be stored by names that you can freely select. The names are stored with the corresponding phone number. This personal phone book encompasses 50 entries.

In general, it is sufficient to just pronounce the name instead of dialing the phone number.

When dialing 1-800 numbers, you may pronounce the first four digits as "One eight hundred" and the system will recognize the spoken entry as "one-eight-zero-zero". All other numeric entries must be spoken as individual numbers.

Likewise, the lock and unlock code can be input using a verbal command.

Even if you are connected to an automated answering system, e.g. a voice mailbox, the voice recognition system can assist you, page 19.

In order to provide for a safe and comfortable dialog, the voice recognition system acknowledges important commands and repeats the request if the stored name cannot be recognized.

The voice recognition system also recognizes if the vehicle's cellular phone is connected to the corresponding mobile wireless network. If the vehicle's cellular phone is not connected/switched on during a dialing procedure, the voice recognition system sends a notification.

The vehicle's cellular phone user keypad remains fully operational.

Dialog description

After the activation of the voice recognition system, an audible tone (beep) is heard. After which the following commands may be spoken:

- “Help” / “Help Phone”
- “Enter Unlock Code”
- “Telephone on”
- “Dial number”
- “Dial Name”
- “Redial”
- “Store Name”
- “Phone book”
- “Delete phone book”
- “Delete name”

After using these commands, the voice recognition system begins the dialog with the user.

An exact description of the dialog flow is found on the following pages.

The dialog flow can be controlled using the following final or edit commands.

Following final commands are possible:

Final command	Comment
“Dial”, “Dial number”, “Dial phone number” or “Send”, “Send number”, “Send phone number” or “Call”, “Call number”, “Call phone number”	The number entered will be dialed.
“Store” or “Store number” or “Store phone number” “Cancel”	The phone number and the name are stored in the phone book. The dialog is concluded

Telephone

Following edit commands are possible:

Edit command	Comment
“Confirm” “Confirm number” “Confirm phone number”	All digits input up to this point in time are repeated for verification. The voice recognition system will prompt you (“go ahead”) to enter additional digits or commands.
“Correct” or “Correction” or “Correct number” or “Correct phone number”	The digit block last entered is deleted. Previously input digit blocks are repeated. The voice recognition system will prompt you (“go ahead”) to enter additional digits or commands..

Edit command	Comment
“Delete” or “Delete number” or “Delete phone number”	All digits input are deleted. The voice recognition system will prompt you (“the number is removed, go ahead”) to enter new digits.

Telephone commands

A complete list of all possible telephone commands can be found starting on page 31.

“Help” / “Help Phone”

The voice recognition system contains an extensive help function.

Help can be accessed anytime in the telephone mode by saying “Help” or “Help Phone”. The voice recognition system will then read out an option list of available functions and commands that can be used.

Note:

You also have the possibility to directly select the help function for a particular component, page 4.

“Enter unlock code”

Use this command to input the code to lock or unlock your telephone. After the command, you are prompted to enter the code. After entering the code,, the voice recognition system repeats the recognized digits and waits until you continue speaking. With an input of more than 3 characters, the voice recognition system advises with “you have entered too many digits” or if less than 3 digits are entered, “you have not entered enough digits”. The system advises the input of an incorrect code with: “The lock code is wrong”.

Sample dialog:

User input	Voice recognition system reply
“Enter unlock code”	“Enter unlock code”
“One-Two-Three”	“One-Two-Three”
“Store”	

Telephone

“Dial Number”

You can dial a phone number using this command.

Digits from “zero” to “nine” may be entered.

The phone number can be spoken as a continuous string of digit blocks (3 to 5 digits in each block) with an approximate 0.5 second pause between the blocks. After each spoken block, the voice recognition system repeats the recognized digits and waits until you continue speaking.

When dialing 1-800 numbers, you may pronounce the first four digits as “One eight hundred” and the system will recognize the spoken entry as “one-eight-zero-zero”. All other numeric entries must be spoken as individual numbers.

With an input of more than 32 digits, the voice recognition system announces, “you have entered too many digits”. Please correct or delete the corresponding digit blocks, see page 13.

Sample dialog:

User input	Voice recognition system reply
“Dial number”	“The number, please”
“One-Eight-0-0”	“One-Eight-0-0”
“Three-Six-Seven”	“Three-Six-Seven”
“Six-Three-Seven-Two”	“Six-Three-Seven-Two”
“Dial”	“Dialing”

Note:

Vehicles with operating lever:

To dial a phone number, you may briefly pull the operating lever to position 1 , instead of using the “Dial” command, pg. 5.

Vehicles with multifunction steering wheel:

To dial a phone number, you may press the  button instead of using the “Dial” command, pg. 7.

“Confirm”

Using this command all spoken digits are repeated. After which you are prompted to continue your input.

Sample dialog:

User input	Voice recognition system reply
“Dial number”	“The number, please”
“One-Eight-O-O”	“One-Eight-O-O”
“Confirm”	“One-Eight-O-O” , go ahead
“Three-Six-Seven”	“Three-Six-Seven”
“Six-Three-Seven-Two”	“Six-Three-Seven-Two”
“Dial”	“Dialing”

“Correction”

Using this command will delete the last entered digit block.

After the command the last digit block is deleted and all previously input digits are repeated. After which you are prompted to continue your input.

Sample dialog:

User Input	Voice recognition system reply
“Dial number”	“The number, please”
“One-Eight-O-O”	“One-Eight-O-O”
“Three-Six-Seven”	“Three-Six-Six”
“Correction”	“One-Eight-O-O” , go ahead
“Three-Six-Seven”	“Three-Six-Seven”
“Six-Three-Seven-Two”	“Six-Three-Seven-Two”
“Dial”	“Dialing”

Telephone

“Delete”

Using this command erases the entire number and asks you to start from the beginning. Use this command if you have mistakenly spoken the wrong number or if the voice recognition system did not understand you properly in several blocks. To correct only one block, use “Correction”.

Sample dialog:

User input	Voice recognition system reply
“Dial number”	“The number, please
“One-Eight-0-0”	“One-Eight-0-0”
“Three-Six-Seven”	“Three-Six-Six”
“Delete”	“The number is removed, go ahead”
“One-Eight-0-0”	“One-Eight-0-0”
“Three-Six-Seven”	“Three-Six-Seven”
“Six-Three-Seven-Two”	“Six-Three-Seven-Two”
“Dial”	“Dialing”

“Store Name”

This command provides you the possibility to create and expand your personal phone book.

After using this command you will be requested to enter a phone number.

Digits from “zero” to “nine” may be entered.

When dialing 1-800 numbers, you may pronounce the first four digits as “One eight hundred” and the system will recognize the spoken entries as “one-eight-zero-zero”. All other numeric entries must be spoken as individual numbers.

The telephone number can be spoken as a continuous string, or with longer phone numbers (more than 5 digits) in the form of digit blocks (3 to 5 digits). After each digit block (separate the digit blocks by using an approximate 0.5 second pause), the voice recognition system repeats the recognized digits and waits until you continue speaking.

With an input of more than 32 digits, the voice recognition system announces, “you have entered too many digits”. Please correct or delete the corresponding digit blocks, page 13.

After the command “Store”, you will be prompted up to four times to input the name.

Note:

The voice recognition system may recognize names even if you have not stored them yourself. For optimum performance, however, call up only names you have stored yourself.

Sample dialog:

User Input	Voice recognition system reply
“Store name” / “Store number”	“The number, please”
“One-Eight-O-O”	“One-Eight-O-O”
“Three-Six-Seven”	“Three-Six-Seven”
“Six-Three-Seven-Two”	“Six-Three-Seven-Two”
“Store”	“The name, please”
“Mercedes-Benz”	“Again”
“Mercedes-Benz”	“Name and number are set”

Telephone

“Dial name” (Telephone book)

Use this command to place a phone call by selecting a name previously stored in your personal phone book.

Sample dialog:

User input	Voice recognition system reply
“Dial name”	“The name, please”
“Schmidt office”	“Schmidt office”
	“Number is Dialed”

Note:

If the voice recognition system does not recognize the name you requested, please refer to the section, “Phone book” on page 18. By following the dialog, you can check and determine if the name is stored in the phone book.

“Delete Name” (Telephone book)

Use this command to delete a name from your personal phone book.

Sample dialog:

User input	Voice recognition system reply
“Delete name”	“The name, please”
“Schmidt office”	“Would you like to remove Schmidt office?”
“Yes”	“The number is removed”



Note:

Any other reply than the word “yes” will end the dialog and the name will not be deleted from the phone book.

“Delete phone book”

Use this command to delete the complete phone book or one or more names from the phone book.

Sample dialog:





User input	Voice recognition system reply	Comment
“Delete phone book”	“Would you like to remove the phone book completely?”	
“Yes”	“Are you sure?”	With another “Yes” the complete phone book is deleted.
“No”	The voice recognition system starts reading the phone book entry by entry.	If the operating lever is briefly pulled back (position 1 ) , or the button  is pressed, the name to be deleted is selected. Page 5, 7.

User input	Voice recognition output	Comment
	“Would you like to remove Schmidt office?”	The selected name is read out once more
“Yes”		The phone book entry is erased and the remaining phone book entries are read out.
“No”	The voice recognition system reads out the phone book entry by entry.	
“Back”	The voice recognition system announces the preceding name: “Would you like to remove Jane Smith?”	You may now continue with the dialog.
“Cancel”		The dialog is concluded.

Telephone

“Phone book”

Use this command to listen to the entire phone book or select an entry.

User input	Comment
“Phone book”	Voice recognition system reads out the complete phone book entry by entry.
Depending on the equipment level of your vehicle, either pull the operating lever to position  or press  button, page 5, 7.	The selected name is announced and the corresponding number is dialed.
Depending on the equipment level of your vehicle, either push the operating lever to position  or press  button, page 5, 7.	The dialog is stopped. This is confirmed to you by the voice recognition system reply “Cancel”.


“Redial”

Use this command to call the last number. The voice recognition system will then dial the number for you again without further confirmation.

Managing an automated answering system/voice-mail operation

Activate the voice recognition system during a phone call to access and manage your answering machine/voice mail. After activation and the tone is heard, you can input (verbally or via the keypad) digits zero to nine, “Star” and “Pound”.

Sample dialog:

Activate the voice recognition system by pulling the operating lever to position 1 .

Voice mail response	User input	Voice mail system reply
“Please enter your extension followed by the pound sign.”	“One-Three-Five-Five-Pound”	“One-Three-Five-Five-Pound”
	“Dial”	


Voice mail response	User input	Voice mail system reply
“Please enter your password followed by the pound sign”.	“Four-Four-Nine-One-Pound”	“Four-Four-Nine-One-Pound”
System continues...	“Dial”	
	Continue dialog...	

Note:

Vehicles with operating lever:

To dial a phone number, you may briefly pull the operating lever to position 1 , instead of using the “Dial” command, pg. 5.

Vehicles with multifunction steering wheel:

To dial a phone number, you may press the  button instead of using the “Dial” command, pg. 6.

You must activate the voice recognition system each time you wish to input your selection and please wait for the voice recognition to confirm your input before using the “Dial” command.

Audio

Audio operation

You have the capability to operate the radio, CD-Player, CD-Changer or the cassette player using verbal commands.

In order to provide for a safe and comfortable dialog, the voice recognition system acknowledges important commands and repeats the request if the stored name cannot be recognized.

Note:

The vehicle's radio must be switched on in order to operate the voice recognition system.

Activate the voice recognition system, (see pages 5, 7) and select the component you wish to control, page 3, e.g. "Radio" or "CD-Changer".

Following Audio components can be operated using voice recognition:

- Radio, page 21
- CD-Player, page 26
- CD-Changer, page 26
- Cassette Player, page 27

Following components can be switched on using voice recognition:

- Navigation, page 28

Radio

The radio can be operated using the voice recognition system. The radio must be switched on prior to the activation of the voice recognition system, page 5, 7. In order to access the radio mode, use the spoken command “Radio” or “Radio on”, page 3.

Subsequently you can also use the following spoken commands.

- “Help radio”
- “Seek”
- Select frequency (FM)
e.g. “Ninety-five point five”
- Select frequency (AM)
e.g. “Frequency six-thirty”
- “AM” / “FM” / “Weatherband”
- “Store station” (Station list)
- “Select station” (Station list)
- “Station list”
- “Delete station” (Station list)
- “Delete station list

Additionally, you have the capability of creating a station list. Frequently listened to radio stations can be stored by names that you can freely select. The names are stored with the corresponding frequencies. This personal station list encompasses 10 entries.

In general, it is sufficient to just pronounce the name instead of pronouncing the station frequency.

An exact description of the commands is found on the following pages.

Audio

Radio commands

A complete list of all possible radio commands can be found starting on, page 33.

“Help Radio“

The voice recognition system contains an extensive help function.

Help can be accessed anytime by saying “Help Radio”. The voice recognition system will then read out an option list of available functions and commands that can be used.

“Seek” / “Next station”

Use this command to activate the seek function to tune to the next station.

Select Frequency “FM”

You may for example, select a frequency in the FM band (87,9 to 107,9 Megahertz) using a verbal command such as, “Ninety-five five”.

The voice recognition system also recognizes the words frequency and point, and you may for example use the command, “Frequency ninety-five point five”.

Select frequency “AM”

You may for example, select a frequency in the AM band (530 to 1710 kilohertz) using a verbal command such as, “Six-thirty or Ten-ten”.

“FM”

“AM”

“Weatherband”

Use this command to change the band.

“Store station” (Station list)

Use this command to store the set station (AM and FM only) by name in your personal station list. After using this command you will be prompted by the voice recognition system to repeat the name two to four times before it is stored in the station list.

Note:

The voice recognition system may recognize names even if you have not stored them yourself. For optimum performance, however, call up only names you have stored yourself.

Sample dialog:

User input	Voice recognition system reply
”Store station”	”Station, please”
”Smooth jazz”	”Again”
”Smooth jazz”	”The station is set”

“Select station” (Station list)

Use this command to select a stored name from your station list.

Sample dialog:

User input	Voice recognition system reply
”Select station”	”Station, please”
”Smooth jazz”	”Smooth jazz”





Note:

If the voice recognition system does not recognize the station name you requested, please refer to the section, “Station list” on page 24. By following the dialog, you can check and determine if the name is stored in the station list.

Audio

“Station list”

Use this command to play the entire station list or to select an entry from the station list.

User input	Comment
“Station list”	The voice recognition system reads out the entire list.
Depending on the equipment level of your vehicle, either pull the operating lever to position  or press  button, pgs. 5, 7.	The selected station is announced and the radio is tuned to the corresponding frequency.
Depending on the equipment level of your vehicle, either push the operating lever to position  or press  button, pgs. 5, 7.	The dialog is stopped. This is confirmed to you by the voice recognition system reply “Cancel”.

“Delete station” (Station list)

Use this command to delete a station from your personal station list.

Sample dialog:

User input	Voice recognition system reply
“Delete station”	“Station, please”
“Smooth jazz”	“Would you like to remove smooth jazz?”
”Yes”	“The station is deleted”



Note:

Any other reply than the word “yes” will end the dialog and the name will not be deleted from the station list.

“Delete station list”

Use this command to delete the complete station list or one or more stations from the station list.

Sample dialog:

User input	Voice recognition system reply	Comment
“Delete station list”	“Would you like to delete the station list completely?”	
“Yes”	“Are you sure?”	With another “Yes” the complete station list is deleted.
“No”	The voice recognition system starts reading the station list entry by entry.	If the operating lever is briefly pulled back (position 1 ) or the button  is pressed, the station to be deleted is selected, page 5, 7.

User input	Voice recognition system reply	Comment
	“Would you like to remove smooth jazz?”	The selected station is read out once more.
“Yes”		The station is erased and the remaining station entries are read out.
“No”	The voice recognition system reads out the station list entry by entry.	
“Back”	The voice recognition system announces the preceding station: “Would you like to remove Classic 100?”	You may now continue with the dialog.
“Cancel”		The dialog is concluded.

Audio

CD-Changer or CD Player

The CD-Changer / CD player can be operated using the voice recognition system. The radio must be switched on prior to the activation of the voice recognition system, page 5, 7.

In order to access the CD-Changer / CD player mode, use the spoken command “CD-Changer” / “Single CD”, page 3.

Subsequently you can also use the following spoken commands:

- “Help CD” / “Help CD-Changer” / “Help Single CD”
- “CD 1” to “CD 6”¹⁾
- ”Next CD”¹⁾
- “Track 1” to “Track 19”
- “Next Track”

¹⁾ only possible with CD-Changer equipped vehicles

CD-Commands

A complete list of all possible CD commands can be found starting on, page 34.

“Help CD” / “Help” CD-Changer” / “Help Single CD”

Help can be accessed anytime by saying the command “Help CD” or “Help CD-Changer / CD Single Player”.

The voice recognition system will then read out an option list of available functions and the commands that can be used.

CD 1” to “CD 6”

Use this command to select up to 6 CDs out of your CD-Changer.

“Next CD”

Use this command to select the next CD.

“Track 1” to “Track 19”

Use this command to select up to 19 title numbers of a loaded CD.

“Next Track”

Use this command to select the next title.

Cassette Player

The cassette player can be operated using the voice recognition system. The radio must be switched on prior to the activation of the voice recognition system, page 5, 7. In order to access the cassette player mode, use the spoken command “Tape”.

Subsequently you can also use the following spoken commands:

- “Help Tape”
- “Next Track”
- “Seek”
- “Other side”
- “Fast forward”
- “Rewind”

Audio

Cassette player commands

A complete list of all possible cassette commands can be found starting on, page 35.

“Help Tape”

Help can be accessed anytime by saying the command “Help Tape”. The voice recognition system will then read out an option list of available functions and commands that can be used.


“Next track / Seek”

Use this command to select the next track on your cassette.

“Other side”

Use this command to change to the other track on the cassette.

“Fast forward” or “Rewind”

Use this command to fast forward or rewind the cassette. Stop the winding action of the cassette player by briefly pushing the operating lever to position 2 .

Navigation

The navigation system can be switched on using voice recognition:

The radio must be switched on prior to the activation of the voice recognition system, page 5, 7. In order to activate the navigation mode, the following commands can be used spoken, page 3:

- “Navi”
- “Navi on”
- “Navigation”
- “Navigation on”

Troubleshooting

Voice recognition does not function


- The vehicle's radio must be switched on in order to use the voice recognition system.
- Voice recognition system must be activated before speaking commands, page 5, 7.

Voice recognition does not recognize commands

- The voice recognition system should only be operated by the driver. The passenger can use the vehicle's cellular phone at any time by picking up the receiver handset.
- It is important to speak in a fluid manner using a normal tone. Speaking unclear, too loud or too soft can result in the inability of the voice recognition system to recognize or to misunderstand your commands.
- Please note that external noise may affect the performance of the voice recognition system. Please take steps to reduce noise by closing all the windows and sunroof.

- Digits from zero to nine, and the words "Pound" and "Star" may be entered.
- Digit blocks with 3 to 5 digits have proven reliable for the input of phone numbers.

Telephone book entry or station list entry is not recognized

- Select names for your phone book and station list with the greatest possible acoustical differences.
Example: Incorrect: Correct:
 Mr. Schmidt Schmidt office
 Mr. Smith Smith Michael
- In the event the voice recognition system does not recognize a telephone book entry (when for example the entry was spoken by another user), page down in your phone book using the command "Phone book" and select the name by pressing the operating lever to position , page 18.

Audio

- Should interference occur during the process of storing a name, the voice recognition system will automatically repeat the procedure one time. If the interference continues, the dialog is stopped. You must repeat the input procedure again.

Which commands are available for use?

- You have the possibility to directly select the help function for a particular component, page 4.
- A complete list of all available commands can be found starting on page 31.

Command list

Following is a complete list of commands that can be recognized by the voice recognition system. The recognition of these commands is dependent on the level of equipment in your vehicle.

Telephone commands

Help commands:

- “Help” / “Help Phone”
- “Help Function”
- “Help Function Phone”

Commands to enter your unlock code:

- “Enter unlock code”
- “Input unlock code”

Commands to enter telephone numbers:

- “Dial number”
- “Dial phone number”
- “Call number”
- “Call phone number”
- “Phone number”
- “Number”

Command to confirm a spoken number or name:

- “Confirm”
- “Confirm number”
- “Confirm phone number”

Commands to correct the last spoken digit blocks:

- “Correct”
- “Correction”
- “Correct number”
- “Correct phone number”

Commands to delete all input digit blocks:

- “Delete”
- “Delete number”
- “Delete phone number”

Commands to create and extend your personal phone book:

- “Store name”
- “Store number”
- “Store phone number”

Operating Tips

Command to dial a name from your personal phone book:

- “Dial name”
- “Call name”
- “Name”

Command to delete a name or number from your personal phone book:

- “Delete name”
- “Delete number”
- “Delete phone number”

Command to delete names from your personal phone book or to completely delete the contents of your telephone book:

- “Delete phone book”

Command to play the phone book or to select an entry from your phone book:

- “Play phone book”
- “Read phone book”
- “Phone book”
- “List phone book”
- “Get phone book”

Command to redial the last dialled telephone number:

- “Redial”
- “Redial number”
- “Redial phone number”
- “Dial last number”
- “Dial last phone number”

Final command to dial a telephone number:

- “Dial”
- “Dial number”
- “Dial phone number”
- “Call”
- “Call number”
- “Call phone number”
- “Send”
- “Send number”
- “Send phone number”
- “OK”

Final command to store a telephone number:

- “Store”
- “Store number”
- “Store phone number”
- “Store name”

Command to stop a dialog:

- “Cancel”

Digits and words used to enter a telephone number:

- “0” - “9”
- “Star”
- “Pound”
- “One eight hundred”

Radio commands

Help commands:

- “Help Radio”

Commands to select the next station:

- “Seek”
- “Radio seek”
- “Tuner seek”
- “Next station”
- “Radio next station”
- “Tuner next station”

Example of a command to select a frequency on the FM and AM band:

- “Ninety-five five“ (FM)
- “Six thirty” (AM)
- “Ten ten” (AM)

Commands to select a band:

- “FM”
- “AM”
- “Weatherband”

Command to enter a station (AM or FM only) into your personal station list:

- “Store station”

Command to select a station from your personal station list:

- “Select station”

Operating Tips

Commands to play the station list or to select an entry from your station list:

- “List station list”
- “Play station list”
- “Get station list”
- “Read station list”
- “Station list”

Command to delete a station from your personal station list:

- “Delete station”

Command to delete stations from your personal station list or to completely delete the contents of your station list:

- “Delete station list”

CD-Changer / CD player commands

Help commands:

- “Help CD”
- “Help CD changer”
- “Help single CD”

Example of commands to select up to 6 CDs in your CDChanger:

- “CD 1”
- “CD number 2”
- “Load CD number3”
- “Select CD 4”
- “Select CD number 6”
- “Load CD 4”

Commands to select the next CD:

- “Next CD”
- “Select next CD”
- “Load next CD”

Example of commands to select up to 19 title numbers of a loaded CD:

- “CD track 1”
- “CD number 4”
- “Track 8”
- “Select track 5”

Commands to select the next title of a loaded CD:

- “Next track”
- “Seek”
- “CD next track”

Cassette player commands

Help commands:

- “Help Tape”

Commands to select the next title:

- “Tape next track”
- “Next track”
- “Seek”
- “Tape seek”
- “Music search”
- “Tape music search”

Command to switch to the other track:

- “Other side”
- “Tape other side”

Commands to fast forward or rewind:

- “Fast forward”
- “Rewind”
- “Tape fast forward”
- “Tape Rewind”

Navigation commands

Commands to switch on the navigation system:

- “Nav”
- “Navi”
- “Nav on”
- “Navi on”
- “Navigation”
- “Navigation on”

Mode Function Commands

Commands to switch on the phone:

- “Telephone”
- “Telephone on”
- “Phone”
- “Phone on”

Commands to switch on the radio:

- “Radio”
- “Radio on”
- “Tuner”
- “Tuner on”

Operating Tips

Commands to switch on the CD player/CD-Changer:

- “CD”
- “CD on”
- “CD-Changer”
- “CD-Changer on”
- ”Single CD”
- “Single CD on”
- “CD number zero”
- “CD Number zero on”
- “CD number 0”
- “CD number 0 on”
- “Select CD number zero”
- “Select CD number 0”
- “Load CD number zero”
- “Load CD number 0”

Commands to switch on the tape player:

- “Tape”
- “Tape on”

A	Commands, CD-Changer / CD player.....	34
	Accept incoming telephone call.....	5
	Activate cellular phone.....	3
	Activate voice recognition system	5, 7
	Answering machine operation	19
	Audio component selection.....	20
	Audio operation	20
C		
	Cassette player.....	27
	Cassette player activation	3
	Cassette player commands	35
	CD commands	26
	CD loading, CD-Changer	26
	CD player	26
	CD player activation.....	3
	CD track - selecting, CD-Changer/CD player	27
	CD-Changer	26
	CD-Changer activation.....	3
	Command list.....	31
	Commands to select FM frequencies	22
	Commands, cassette player	27, 28, 35
	Commands, CD	26
	Commands, CD-Changer / CD player.....	34
	Commands, mode function	35
	Commands, navigation	28, 35
	Commands, radio.....	21, 22, 33
	Commands, telephone	11, 31
	Confirming spoken digits.....	13
	Correcting digit blocks during input	13
D		
	Deactivate voice recognition system.....	5, 7
	Delete (complete telephone book)	17
	Delete name.....	16
	Delete number during input	14
	Delete station (station list)	24
	Delete station list (complete)	25
	Dial number.....	12
	Dial telephone number	12
	Dialog description, telephone.....	9
	Digits.....	12
E		
	Edit commands, telephone.....	10

- F**
 Fast forward, cassette player 28
 Final commands, telephone 9
 FM band, select frequency 22
- H**
 Help 4
 Help cassette 4, 28
 Help CD 4
 Help CD player 26
 Help CD-Changer 26
 Help radio 4, 22
 Help telephone 4, 11
- L**
 Load next CD, CD-Changer 26
- M**
 Messages in multifunction display 8, 9
 Mode function commands 35
 Multifunction display 8
 Multifunction steering wheel with operating lever 7
- N**
 Navigation (switching on) 28
- Navigation commands 35
 Navigation system activation 3
 Next station, radio 22
 Next track, cassette player 28
 Next track, CD-Changer/CD player 27
- O**
 Operating lever 5
 Other side, cassette player 28
 Other station, radio 22
- P**
 Play station list 24
- R**
 Radio activation 3
 Radio commands 22, 33
 Radio operation 21
 Receive incoming telephone call 6, 7
 Receiving an incoming telephone call 9
 Rewind, cassette player 28

S	
Seek other track, cassette player	28
Select a phone book entry	9
Select frequency, radio	22
Select station (station list)	23
Selecting audio components	3
Set radio frequency	22
Station seek, radio	22
Store name, telephone book	14
Store station, (station list)	23
T	
Telephone commands	9, 11, 31
Telephone number, allowable digits	14
Telephone number, correcting during input	13
Telephone operation	8
Troubleshooting	29
V	
Voice mailbox operation	19
Volume setting	6, 7

Mercedes-Benz USA, LLC
One Mercedes Drive
Montvale, New Jersey 07645
www.MBUSA.com

(c) 2000 Mercedes-Benz USA, LLC
Technical Information
Order number P-2710-00A
Printed in the United States

All illustrations and specifications contained in this folder are based on the latest product information available at the time of publication approval. Mercedes-Benz reserves the right to make changes at any time, without notice.