

Item	Designation	Coordinates
<u>A0</u>	Use of wiring diagrams	64L
<u>Code 362</u>	HERMES LTE	41D
<u>Code B54</u>	Live Traffic Information	41D
<u>Code B63</u>	Sporty engine sound	9C
<u>Code FA</u>	CABRIOLET	2F 33C
<u>Code FC</u>	COUPE	2G 28C
<u>Code L</u>	LEFT-HAND DRIVE	13F 17F 39C
<u>Code R</u>	RIGHT-HAND DRIVE	13G 17G 38C
<u>H4/1</u>	Left front door midrange speaker	15L
<u>H4/2</u>	Right front door midrange speaker	19L
<u>H4/27</u>	Center instrument panel speaker	42L
<u>H4/33</u>	Left front door tweeter	17L
<u>H4/34</u>	Right front door tweeter	21L
<u>H4/42</u>	Left front footwell woofer	6L
<u>H4/43</u>	Right front footwell woofer	8L
<u>H4/62</u>	Left rear surround sound system midrange speaker	30L
<u>H4/63</u>	Right rear surround sound system midrange speaker	31L
<u>H4/70</u>	Left rear door sound system tweeter	24L
<u>H4/71</u>	Right side paneling sound system tweeter	27L
<u>H4/80</u>	Left rear door sound system midrange speaker	22L
<u>H4/81</u>	Right side paneling sound system midrange speaker	26L
<u>H4/93</u>	Left rear surround sound system midrange speaker	34L
<u>H4/95</u>	Right rear shelf surround sound system midrange speaker	37L

Item	Designation	Coordinates
<u>K40/5</u>	Rear fuse and relay module	3L
<u>K40/5f475</u>	Fuse 475	2L
<u>N40/3</u>	Sound system amplifier control unit	3A 13A 20A 27A 36A 44A 53A
<u>N112/9</u>	HERMES control unit	46L 54L
<u>W6/1</u>	Left taillamp trunk ground point	3G
<u>W7</u>	Right wheelhouse trunk ground point	3F
<u>X18/53</u>	Driver-side cockpit/frame floor assembly electrical connector	39G 42F
<u>X18/54</u>	Passenger-side cockpit/frame floor assembly electrical connector	39F 42G
<u>X23/5</u>	Electrical connector / soft top compartment lid	33F 33H
<u>X23/28</u>	Rear shelf surround sound system electrical connector	29F
<u>X30/21</u>	Drive train CAN (CAN C1) potential distributor electrical connector	11L
<u>X35/1</u>	Driver door electrical connector	14F 19G
<u>X35/2</u>	Front passenger door electrical connector	14G 19F
<u>Z28/1</u>	Left front seat crossmember ground point connector sleeve 2	22F 34D
<u>Z28/2</u>	Right front seat crossmember ground point connector sleeve 2	24F 33D
<u>Z28/3</u>	Right rear speaker group connector sleeve (signal +)	25F 37D
<u>Z28/4</u>	Right rear speaker group connector sleeve (signal -)	27F

Item	Designation	Coordinates
<u>Z35/10z1</u>	MOST wake-up signal connector sleeve	51E
<u>CAN C1</u>	Drive train CAN	12K