AF07.61-P-2000-01A	Learning in recirculated air flap actuator	ENGINE 111.981 in MODEL 203.747	
1 When ignition is switched off press flap slightly past limp- home position.		3 Switch ignition on for approx. 45 seconds, switch ignition back off again and wait for processor shut-off delay.	
i 90° position must be changed manually. The processor shut-off delay has a duration of approx. 5 seconds.		i The learn-in procedure for the recirculated air flap is then completed.	

2 Switch on ignition for approx. 15 seconds, switch ignition back off again and wait for processor shut-off delay.