



ELECTRONIC STABILITY PROGRAM (ESP)





№	Код	Замена	К-во	Вар-т	Название	Информация	Примечания
010	<a href="#">2035460643</a>		001		BRACKET	TRANSVERSAL ACCELERATION SENSOR	
020	<a href="#">1635420618</a>		001		SENDER UNIT	TRANSVERSAL ACCELERATION SENSOR	
030	<a href="#">0119883278</a>		001		CLIP		
040	A0025427218	<a href="#">0025429418</a>	-		SENDER UNIT		
040	A0025429418	<a href="#">0035422318</a>	-		SENDER UNIT		
040	<a href="#">0035422318</a>		001		SENDER UNIT	TURN RATE SENSOR	
050	<a href="#">910112006003</a>		002		NUT	SENSOR TO BRACKET	M6
060	<a href="#">0025428918</a>		001		SENSOR	LATERAL ACCELERATION/YAW RATE	<a href="#">*046</a> <a href="#">*047</a> <a href="#">*048</a>
060	<a href="#">2095420018</a>		001		SENSOR	LATERAL ACCELERATION/YAW RATE	<a href="#">*050</a> <a href="#">*049</a> <a href="#">*070</a>
080	<a href="#">2035403713</a>		001	L	CABLE HARNESS	ESP FLOOR ASSEMBLY	<a href="#">*154</a> <a href="#">*155</a> <a href="#">*157</a> <a href="#">*158</a>

080	<a href="#">2034400613</a>		001	L	CABLE HARNESS	ESP FLOOR ASSEMBLY	<a href="#">*159</a> <a href="#">*160</a> <a href="#">*046</a> <a href="#">*047</a>
080	<a href="#">2035401432</a>		001	L	ELECTRIC CABLE	ESP FLOOR ASSEMBLY	<a href="#">*049</a> <a href="#">*050</a>
080	<a href="#">2035403813</a>		001	R	CABLE HARNESS	ESP FLOOR ASSEMBLY	<a href="#">*155</a> <a href="#">*156</a> <a href="#">*158</a> <a href="#">*161</a>
080	<a href="#">2034400713</a>		001	R	CABLE HARNESS	ESP FLOOR ASSEMBLY	<a href="#">*162</a> <a href="#">*160</a> <a href="#">*048</a> <a href="#">*047</a>
080	<a href="#">2035401532</a>		001	R	ELECTRIC CABLE	ESP FLOOR ASSEMBLY	
080	<a href="#">2035404313</a>		001	L	CABLE HARNESS	ESP FLOOR FRAME ASSY, PARAMETER STEERING	<a href="#">*157</a> <a href="#">*158</a>
080	<a href="#">2034401213</a>		001	L	CABLE HARNESS	ESP FLOOR FRAME ASSY, PARAMETER STEERING	<a href="#">*159</a> <a href="#">*160</a> <a href="#">*046</a> <a href="#">*047</a>
080	<a href="#">2035402032</a>		001	L	ELECTRIC CABLE	ESP FLOOR FRAME ASSY, PARAMETER STEERING	
080	<a href="#">2035404413</a>		001	R	CABLE HARNESS	ESP FLOOR FRAME ASSY, PARAMETER STEERING	<a href="#">*158</a> <a href="#">*161</a>
080	<a href="#">2035402132</a>		001	R	ELECTRIC CABLE	ESP FLOOR FRAME ASSY, PARAMETER STEERING	
080	<a href="#">2034401313</a>		001	R	CABLE HARNESS	ESP FLOOR FRAME ASSY, PARAMETER STEERING	<a href="#">*162</a> <a href="#">*160</a>
100	<a href="#">2035404508</a>		001	L	CABLE HARNESS	ESP FLOOR ASSEMBLY	<a href="#">*152</a>
100	A2035404808	<a href="#">2035408409</a>	-	R	CABLE HARNESS		
110	<a href="#">2205400681</a>		001		PIN BUSHING HOUSING	THREE PIN, PRESSURE SENSOR	3-PIN
130	<a href="#">2105402181</a>		001		PIN BUSHING HOUSING	BRAKE BOOSTER	3-PIN
140	<a href="#">2205400081</a>		001		PIN BUSHING HOUSING	BRAKE BOOSTER	6-PIN
140	<a href="#">2205400081</a>		001		PIN BUSHING HOUSING		6-PIN;B24/15
150	<a href="#">0315450628</a>		001		PLUG HOUSING	FRONT AXLE DISTRIBUTOR CONNECTOR LEFT	4-PIN
150	<a href="#">0015456940</a>		001		PLUG HOUSING		4-PIN;TO A 031 545 06 28
160	<a href="#">2105402081</a>		001		PIN BUSHING HOUSING	PARAMETRIC STEERING	2-PIN
170	<a href="#">0385452128</a>		001		HOUSING	PLUG CONNECTION RIGHT FRONT AXLE DISTRIBUTOR	4-PIN;X62/6
170	<a href="#">0015456940</a>		001		PLUG HOUSING		4-PIN;TO A 038 545 21 28
200	<a href="#">2105457628</a>		001		PLUG HOUSING	STOP LIGHT SWITCH	4-PIN
210	<a href="#">0375455928</a>		001		PIN	POTENTIAL	2-PIN

				BUSHING HOUSING	DISTRIBUTOR	
220	<a href="#">0375450628</a>		001	PLUG HOUSING	CONNECTOR TRACTION SYSTEM	4-PIN
230	<a href="#">2105402181</a>		001	PIN BUSHING HOUSING	ROTATIONAL SPEED SENSOR	3-PIN
240	<a href="#">0025456540</a>		001	CONTACT CARRIER	REAR AXLE TRANSFER CASE PLUG-CONNECTION	4-PIN;VIOLETT
240	<a href="#">0025456440</a>		001	CONTACT CARRIER	REAR AXLE TRANSFER CASE PLUG-CONNECTION	4-PIN;BLAU
240	<a href="#">0025456240</a>		001	CONTACT CARRIER	REAR AXLE TRANSFER CASE PLUG-CONNECTION	4-PIN;SCHWARZ
300	<a href="#">0005402305</a>		NB	REP.SET CONTACT		0.5 MM2 MQS <a href="#">*101</a>
300	<a href="#">0005402405</a>		NB	REP.SET CONTACT		0.75 MM2 MQS <a href="#">*101</a>
330	<a href="#">0355457328</a>		NB	PLUG		0.5-1.0MM2 SLK
340	<a href="#">0005458780</a>		NB	BLIND PLUG		
440	<a href="#">0115458126</a>		NB	CONTACT SPRING		0.5-1.0MM2 JPT
450	<a href="#">0005404505</a>		NB	REP.SET CONTACT		0.5 MM2 MQS <a href="#">*101</a>