


AR68.30-P-1060PB

Removing and installing bottom tailgate paneling


29.5.00

MODEL 203.7

1 Spreading clip
2 Catch lug



P68.30-2270-06

	Removing, installing
1	Remove spreading clips (1) from bottom tailgate paneling and at tailgate handle
2	Pull catch lugs (2) out of tailgate handle
3	Remove tailgate handle
4	Remove bottom tailgate paneling

5

Install in the reverse order