


Camshaft Timing Network



- B6/4 – Camshaft position sensor (intake left)
- B6/6 – Camshaft position sensor (exhaust left)
- B6/7 – Camshaft position sensor (exhaust right)
- B6/5 – Camshaft position sensor (intake right)
- B11/4 – Engine coolant temperature sensor
- B70 – Crankshaft hall sensor
- B2/5 – MAF
- N3/10 – ME 9.7
- Y49/5 – Camshaft timing control solenoid (exhaust right)
- Y49/7 – Camshaft timing control Solenoid (Intake right)
- Y49/4 – Camshaft timing control solenoid (intake left)
- Y49/6 – Camshaft timing control Solenoid (exhaust left)